



Installation and maintenance manual
Manuel d'installation et de maintenance
Installations- und Wartungshandbuch
Manuale di installazione e di manutenzione
Manual de instalación y de mantenimiento

Airwell



XLM OG 18 I.R.



XLM OG 18

English

Français

Deutsch

Italiano

Español



WATER CHILLER INDOOR UNIT
UNITÉ INTÉRIEURE MURALE EAU GLACÉE
WANDINNENTEIL KALWASSER
UNITÀ MURALE INTERNA ACQUA REFRIGERATA
UNIDAD INTERIOR MURAL AGUA REFRIGERADA

IOM XLM 01-A-2ALL

Part number / Code / Teil Nummer / Codice / Código : **3990153**
Supersedes / Annule et remplace / Annuliert und ersetzt /
Annulla e sostituisce / Anula y sustituye : **IOM XLM 01-A-1ALL**



INSTALLATION INSTRUCTION

NOTICE D'INSTALLATION

INSTALLATIONSHANDBUCH

ISTRUZIONI INSTALLAZIONE

INSTRUCCIONES DE INSTALACIÓN

English

Français

Deutsch

Italiano

Español

CONTENTS

GENERAL RECOMMENDATIONS	3
SAFETY DIRECTIONS	3
WARNING	3
INSPECTION AND STORAGE	4
WARRANTY	4
CONTENTS OF PACKAGE	4
DIMENSIONS	5
TECHNICAL SPECIFICATIONS	5
UNIT WITHOUT VALVE , WITHOUT ELECTRIC HEATING	6
UNIT WITHOUT VALVE , WITH ELECTRIC HEATING 1590 W	7
CURVE OF PRESSURE DROP	8
INSTALLATION	9
LOCATION OF THE INDOOR UNIT	9
CLEARANCE	9
INSTALLATION OF THE ASSEMBLY PANEL	9
BORING THE WALL FOR PASSAGE OF THE HYDRAULIC PIPES	10
ASSEMBLY AND REMOVAL OF THE APPLIANCE FROM THE ASSEMBLY PANEL	10
CONNECTION OF HYDRAULIC LINKS	10
ASSEMBLY OF THE DRAINPIPE	11
FINAL OPERATIONS	12
MAINTENANCE AND REPAIRS SHOULD BE CARRIED OUT BY QUALIFIED SPECIALISTS.....	12
CLEARING THE AIR CONDITIONER	12
PRECAUTIONARY MEASURES TO BE TAKEN AT THE BEGINNING OF THE SEASON	12
UNIT INFRA RED - INFRA RED REMOTE CONTROL.....	13
USE	13
THERMOSTAT LOCATION	13
ELECTRICAL CONNECTIONS	14
UNIT CONTROLS AND WARNING LIGHTS.....	15
ROOM THERMOSTAT TRM-VP AND TRM-FA	16
USE	16
SWITCHES	16
THERMOSTAT LOCATION	16
DIMENSIONS	17
WALL MOUNTING	17
ELECTRICAL CONNECTIONS	17
TECHNICAL CHARACTERISTICS	17
INSTALLATION OF PIPE THERMOSTAT (CHANGE OVER)	18
CONNECTION OF THE CHANGE-OVER SWITCH	18
FINAL OPERATIONS	19
ADJUSTMENT OF THE TEMPERATURE RANGE	19
ADJUSTMENT PROCEDURE	19
TAE20 AMBIENCE THERMOSTAT.....	20
FIELDS OF APPLICATION	20
DESCRIPTION	20
WIRING DIAGRAM	21
RESET SAFETY DEVICE	21



**POWER SUPPLY MUST BE
SWITCHED OFF
BEFORE STARTING TO
WORK IN THE ELECTRIC
CONTROL BOX**

GENERAL RECOMMENDATIONS

Please read the following safety precautions very carefully before installing the unit.

SAFETY DIRECTIONS

Follow the safety rules in forces when you are working on your appliance.

The installation, commissioning and maintenance of these units should be performed by qualified personnel having a good knowledge of standards and local regulations, as well as experience of this type of equipment.

The unit should be handled using lifting and handling equipment appropriate to the unit's size and weight.

Any wiring produced on site must comply with the corresponding national electrical regulations.

Make sure that the power supply and its frequency are adapted to the required electric current of operation, taking into account specific conditions of the location and the current required for any other appliance connected with the same circuit.

The unit must be EARTHED to avoid any risks caused by insulation defects.

It is forbidden to start any work on the electrical components if water or high humidity is present on the installation site.

WARNING

Cutoff power supply before starting to work on the appliance.

When making the hydraulic connections, ensure that no impurities are introduced into the pipe work.

The manufacturer declines any responsibility and the warranty becomes void if these instructions are not respected.

If you meet a problem, please call the Technical Department of your area.

If possible, assemble the compulsory or optional accessories before placing the appliance on its final location. (see instructions provided with each accessory).

In order to become fully familiar with the appliance, we suggest to read also our Technical Instructions.

-The informations contained in these Instructions are subject to modification without advance notice.

INSPECTION AND STORAGE

At the time of receiving the equipment carefully cross check all the elements against the shipping documents in order to ensure that all the crates and boxes have been received. Inspect all the units for any visible or hidden damage.

In the event of shipping damage, write precise details of the damage on the shipper's delivery note and send immediately a registered letter to the shipper within 48 hours, clearly stating the damage caused. Forward a copy of this letter to the manufacturer or their representative.

Never store or transport the unit upside down. It must be stored indoors, completely protected from rain, snow etc. The unit must not be damaged by changes in the weather (high and low temperatures). Excessively high temperatures (above 60 °C) can harm certain plastic materials and cause permanent damage. Moreover, the performance of certain electrical or electronic components can be impaired.

WARRANTY

The appliances are delivered fully assembled, factory tested and ready to operate.

Any modification to the units without the manufacturer's prior approval, shall automatically render the warranty null and void.

The following conditions must be respected in order to maintain the validity of the warranty:

- Commissioning shall be performed by specialised technicians from technical services approved by the manufacturer.
- Maintenance shall be performed by technicians trained for this purpose.
- Only Original Equipment spare parts shall be used.
- All the operations listed in the present manual shall be performed within the prescribed SCHEDULE.



THE WARRANTY SHALL BE NULL AND VOID IN THE EVENT OF NON-COMPLIANCE WITH ANY OF THE ABOVE CONDITIONS.


CONTENTS OF PACKAGE

1 unit with or without 3-way control valve and with or without electric heating.

Accessoires fournis :

- 1 assembly panel
- 4 screws, washers, pegs
- 1 installation instructions
- 2 fiber seals Ø 15 X 21
- 1 remote control panel (option)
- 1 change-over sensor (unit with valve) (option)
- 2 plastic wire tire (option)
- 1 plaited shaft (option)
- 3 Clips 6, 35 with post isolating (option)

DIMENSIONS



TECHNICAL SPECIFICATIONS

- Type of male coupling Gas 3/4"
- Flexible connection Ø 12mm
- Draining Ø 13mm
- Electric heating capacity 1590W

TYPE OF APPLIANCE	WITHOUT VALVE	WITH VALVE	WITH HEATING
~ 230 V -50 Hz			
HEATING OR COOLING + VENTILATION + ELECTRIC HEATING			
Nominal current A	0.2	0.22	7.12
Maximum current A	0.27	0.29	8.65
Fuse rating gG A	1	1	10
Fuse rating ASE/VDE A	2	2	10
Power supply cable mm ²	3 G 1.5	3 G 1.5	3 G 1.5
Linking XLM / TAE20			
Cable section mm ²	5 x 0.75	7 x 0.75	9 x 0.75

WATER INTAKE TEMPERATURE LIMIT

HIGH = 50°C

LOW = 5°C

IMPORTANT

* These datas are given for guidance only. They must be checked at commissioning according to prevailing standards. They depend on the installation and the cables used.

A main fuse must mandatorily be provided on the power supply.

- Fuses not supplied
- Cables not supplied

UNIT WITHOUT VALVE , WITHOUT ELECTRIC HEATING

Water mode	Inlet air temperature Relative humidity			Ventilation speed		
				PV 603 m3/h	MV 753 m3/h	GV 873 m3/h
6°C / 11°C	27°C	Pt	kW	3.095	3.750	4.116
	47%	Ps		2.379	2.876	3.284
	25°C	Pt		2.548	3.094	3.392
	50%	Ps	kW	2.054	2.488	2.845
	23°C	Pt		2.021	2.331	2.560
	50%	Ps		1.830	2.162	2.490
7°C / 12°C	27°C	Pt	kW	2.754	3.340	3.660
	47%	Ps		2.231	2.698	3.090
	25°C	Pt		2.235	2.714	2.977
	50%	Ps	kW	1.923	2.323	2.674
	23°C	Pt		1.826	2.099	2.255
	50%	Ps		1.740	2.061	2.255
8°C / 13°C	27°C	Pt	kW	2.437	2.957	3.242
	47%	Ps		2.098	2.539	2.921
	25°C	Pt		2.017	2.376	2.609
	50%	Ps	kW	1.829	2.184	2.523
	23°C	Pt		1.650	1.906	2.044
	50%	Ps		1.650	1.906	2.044
10°C / 15°C	27°C	Pt	kW	1.949	2.312	2.552
	47%	Ps		1.903	2.282	2.552
	25°C	Pt		1.645	1.902	2.041
	50%	Ps	kW	1.645	1.902	2.041
	23°C	Pt		1.355	1.571	1.636
	50%	Ps		1.355	1.571	1.636

Pt=Total capacity Ps=Sensible capacity

Water mode	Inlet air temperature			Ventilation speed		
				PV 658 m3/h	MV 774 m3/h	GV 857 m3/h
40°C / 30°C	27°C	Pt	kW	2.062	2.236	2.348
	25°C	Pt		1.922	2.077	2.179
	23°C	Pt		1.777	1.918	2.010
45°C / 35°C	27°C	Pt	kW	2.958	3.289	3.518
	25°C	Pt		2.776	3.086	3.297
	23°C	Pt		2.589	2.879	3.076
50°C / 40°C	27°C	Pt	kW	3.896	4.340	4.642
	25°C	Pt		3.719	4.141	4.431
	23°C	Pt		3.541	3.940	4.216

REMINDER

ANTIFREEZE MANDATORY

Protection system complying with STANDARD to be provided.



UNIT WITHOUT VALVE , WITH ELECTRIC HEATING 1590 W

Water mode	Inlet air temperature Relative humidity			Ventilation speed		
				PV 603 m3/h	MV 753 m3/h	GV 873 m3/h
6°C / 11°C	27°C	Pt	kW	2.620	2.086	3.332
	47%	Ps		1.956	2.287	2.481
	25°C	Pt	kW	2.127	2.516	2.719
	50%	Ps		1.675	1.958	2.133
	23°C	Pt	kW	1.643	1.840	1.996
	50%	Ps		1.471	1.668	1.824
7°C / 12°C	27°C	Pt	kW	2.309	2.721	2.936
	47%	Ps		1.823	2.126	2.313
	25°C	Pt	kW	1.841	2.181	2.358
	50%	Ps		1.554	1.813	1.978
	23°C	Pt	kW	1.484	1.663	1.753
	50%	Ps		1.401	1.593	1.720
8°C / 13°C	27°C	Pt	kW	2.023	2.386	2.574
	47%	Ps		1.703	1.982	2.159
	25°C	Pt	kW	1.640	1.890	2.044
	50%	Ps		1.470	1.693	1.847
	23°C	Pt	kW	1.341	1.509	1.595
	50%	Ps		1.341	1.509	1.595
10°C / 15°C	27°C	Pt	kW	1.585	1.849	1.997
	47%	Ps		1.528	1.766	1.932
	25°C	Pt	kW	1.338	1.507	1.594
	50%	Ps		1.338	1.507	1.594
	23°C	Pt	kW	1.102	1.243	1.315
	50%	Ps		1.102	1.243	1.315

Pt=Total capacity Ps=Sensible capacity

Water mode	Inlet air temperature			Ventilation speed		
				PV 658 m3/h	MV 774 m3/h	GV 857 m3/h
40°C / 30°C	19°C	Pt	kW	1.684	1.925	2.041
	20°C	Pt		1.565	1.787	1.863
	21°C	Pt		1.444	1.648	1.718
45°C / 35°C	19°C	Pt	kW	2.452	2.933	3.111
	20°C	Pt		2.296	2.752	2.919
	21°C	Pt		2.142	2.568	2.724
50°C / 40°C	19°C	Pt	kW	3.239	3.856	4.091
	20°C	Pt		3.091	3.683	3.905
	21°C	Pt		2.942	3.505	3.719




REMINDER

ANTIFREEZE MANDATORY

Protection system complying with STANDARD to be provided.

CURVE OF PRESSURE DROP




INSTALLATION

LOCATION OF THE INDOOR UNIT

Select a location taking into account the following points:

- The indoor units (ST) can be installed in 2 different rooms. The INDOOR UNIT should not be installed in a bathroom or a laundry.
- The location should be well aired without any object or piece of furniture standing in the way; the air should circulate freely.
- Do not place the appliance close to a heatsource, do not expose it directly to sunrays.
- The location should allow easy connection of the power supply, of the cooling pipes and condensate drain.
- The unit should be mounted on a wall sturdy enough to withstand the weight of the appliance.
- The panel of assembly should be installed as shown in the diagram below.

CLEARANCE




INSTALLATION OF THE ASSEMBLY PANEL

Place the assembly panel horizontally on the wall, as shown, by means of a bubble level .

Mark the position of the four holes of the panel on the wall and drill these holes to be filled with pegs.

Assemble the panel on the wall with the four screws. Tighten the screws.



BORING THE WALL FOR PASSAGE OF THE HYDRAULIC PIPES


Mark the position of the hole at each side of the assembly panel as shown on the diagram, next drill these holes under an angle of 5° downwards.

The hole downwards allows to avoid condensates or rain to enter inside.


Place a standard plastic tube Ø 70 mm in the hole.

One can also run the hydraulic connections in a chute again the wall. To do this, enlarge the pre-recessed part of the plastic bottom in order to the able to position the inlet and outlet hoses as well as the condensate drainage line.

- A Outside dimension
- B Inside dimension
- 1 Drill press Ø 70 mm
- 2 Wall



Pre-recessed part to be enlarged for passage in the chute



ASSEMBLY AND REMOVAL OF THE APPLIANCE FROM THE ASSEMBLY PANEL


See to it that the hydraulic links (insulated with 9mm thickness in the case of elastomer line, and 13mm in the case of copper line), the electric cables and the drainpipe are insulated by means of an appropriate tube ("Armaflex" type, 5 mm thickness); they should be covered all together with a plastic, non-adhesive strip, and passed through the hole of the wall.

Hang the indoor unit on the 2 hooks located close to the upper edge of the assembly panel. Press the lower part of the indoor unit against the assembly panel until the latches interlock in the slots and lock the indoor unit on the assembly panel. Check that the unit is well locked on the panel by pulling the unit.


In order to remove the unit from the mounting plate, raise and pull outward.

➤ Make sure that the hooks are locked.

- 1 Indoor unit
- 2 Fixing latch
- 3 Upper hooks
- 4 Lower hooks



- 1 Assembly panel
- 2 Lower hooks
- 3 Lifting
- 4 Pulling



CONNECTION OF HYDRAULIC LINKS

When making the connection

➤ **be sure to connect the entry water supply to the link with a colored stain on the nut.**



The appliance should be cut off by putting stop valves on the water supply.




ASSEMBLY OF THE DRAINPIPE

Connect the drainpipe with the flexible tube in the seat at the rear of the indoor unit.

- 1 Drainpipe
- 2 Fastening clip
- 3 Downwards plane



Place the pipe against the hydraulic pipes and the electric cables.




- 1 Electric cable
- 2 Hydraulic pipe
- 3 Drainpipe

Check that the drainpipe is running downwards.

Avoid siphons and bends when installing the drainpipe.

The end of the pipe should be under waterlevel.


- 1 Siphon
- 2 Bend
- 3 End dipping into water



For an outlet at the left, lay the drainpipe in the seat at the rear of the unit.

If the location selected requires to use long horizontal sections of the drainpipe, provide for an opening at the top of the pipe to avoid overflow of the condensing tray.

- 1 Opening
- 2 Draining condensates downwards
- 3 Drainpipe




After having finished the installation, test the draining by pouring at least two liters of water into the condensing tray. Check that water is freely being drained.

FINAL OPERATIONS

If needed fix the cables and the linking pipes on the wall with collar clamps.

Start operating the airconditioner in the presence of the user and explain all the functions.

Show how to remove the filters, to clean them and to place them back.



MAINTENANCE AND REPAIRS SHOULD BE CARRIED OUT BY QUALIFIED SPECIALISTS

Before carrying out any servicing operations, check that the air conditioner is disconnected.

In order to remove the air filter, lift the front panel, push the filter slightly upward in order to unlock them.

DO NOT OPERATE THE AIR CONDITIONER WITHOUT THE FILTER!

Note : The filter should be cleaned at least once a month.

CLEARING THE AIR CONDITIONER

Rub the indoor unit with a soft, dry cloth or else clean it with a vacuum cleaner.

Do not use hot water or volatile detergent products which may damage the outside of the air conditioner.

PRECAUTIONARY MEASURES TO BE TAKEN AT THE BEGINNING OF THE SEASON

Check that there are no obstacles to the air which is sucked in and blown out, on both the indoor and outdoor units.

Check that the air conditioner is properly connected.

We recommend that the appliance be maintained by qualified specialists (cleaning the turbine, condensates tray, etc...)

UNIT INFRA RED - INFRA RED REMOTE CONTROL



This accessory is compatible with a chilled water or hot water 2 pipes water terminal. This unit is always delivered with a changes over sensor installed into factory.

USE

Two modes available:


- Cooling
- Heating
- Auto

For each of these modes, fan ventilation can be configured in LS, MS, HS and Auto Ventilation modes.

For certain conditions of use, a 5 minute time delay is required at start up. During these 5 minutes, the remote control is inoperative.

THERMOSTAT LOCATION

The unit must be installed and fitted in accordance with current safety standards by a qualified technician.




Our prospectus contains all the information concerning application possibilities and installation dimensions and, in particular, the thermostat's technical characteristics.

Fitting height: about 1.50 m above floor level.

Take care not to locate the thermostat in draughts created by doors and windows.


Also ensure that the thermostat is located in the room's normal thermal currents and that it is not located in shelving or covered by curtains.

Any source of parasitic heat negatively influences temperature regulation accuracy. Therefore, avoid the sun's rays or proximity to portable heating devices, electric lights, chimneys, televisions, etc...



ELECTRICAL CONNECTIONS

CLIMATISEUR MURAL EAU GLACEE IR
 IR WALL MOUNTED CHILLED WATER AIR CONDITIONER
 CLIMATIZADORES MURAL AGUA HELADA IR



SE 2987 B
 CODE: 399382

MV MOTEUR VENTIL. 3 VITESSES	MV FAN MOTOR 3 SPEED
CV CONDENSATEUR	CV CAPACITOR
X1 BORNIER	X1 TERMINAL STREEP
PCB CARTE PROCESSEUR	PCB GENERAL CONTROLLER
ST1 SONDE D' AMBIANCE ROOM	ST1 ROOM TEMP. SENSOR
ST2 SONDE TEMP. ENTREE EAU	ST2 INLET WATER TEMP. SENSOR
R1 RESISTANCE 3,9 Kohm	R1 3,9 Kohm RESISTOR
MS MOTEUR VOLETS	MS DUMPER STEP MOTOR

UNIT CONTROLS AND WARNING LIGHTS

A STANDBY light

- Lights up when the air conditioner is connected to the power supply and is ready to receive instructions from the remote control.



B OPERATION light

- Lights up during operation. It flashes to confirm that the signal from the remote control has been received and memorised.

C TIMER light

- Lights up when the timer and the night time slow running (SLEEP) – energy savings function are operating.

D FILTER light

- Lights up to indicate that the air filter needs cleaning.

E Light

- COOLING.

F Button

- OPERATION in COOLING / HEATING / ON / OFF MODES.

- Used for stopping (OFF) or starting (ON) the unit in COOLING or HEATING mode without using the remote control.

G Light

- HEATING.


H ACTIVATION key

- Press to turn off the warning light and for reactivating its operation.

- Press for cancelling the audible signal.

I SIGNAL receiver

- Receives signals from the remote control



ROOM THERMOSTAT TRM-VP AND TRM-FA

USE

The room thermostat of the air conditioner regulates the room temperature. It is designed for closed, dry rooms such as flats, offices, etc.



Maximum acceptable relative humidity of the air : 95%. This value should not be exceeded.

Avoid condensation.

SWITCHES

Linear switch



High Speed



Medium speed



Low Speed

Switch 0 - I

➤ ON "I"

➤ OFF "0"

Linear switch

➤ COOLING



➤ HEATING



THERMOSTAT LOCATION

The unit must be installed and fitted in accordance with current safety standards by a qualified technician.

The best location is opposite the source of heat, on an inside wall.


Our prospectus contains all the information concerning application possibilities and installation dimensions and, in particular, the thermostat's technical characteristics.

Fitting height: about 1.50 m above floor level.


Take care not to locate the thermostat in draughts created by doors and windows.

Also ensure that the thermostat is located in the room's normal thermal currents and that it is not located in shelving or covered by curtains.

Any source of parasitic heat negatively influences temperature regulation accuracy. Therefore, avoid the sun's rays or proximity to portable heating devices, electric lights, chimneys, televisions, etc...



DIMENSIONS



WALL MOUNTING

- Remove the thermostat control knob, the screw and the cover.
- On a flat surface, mount the control panel using plugs and screws.
- Install the cover, the screw and the thermostat control knob.

ELECTRICAL CONNECTIONS

Connection of the thermostat **TRM-VP** and **TRM-FA**.

Connections should be made according to the diagram (SEE APPENDIX).

Max. cross-sectional area of wires : 2,5 mm²

TECHNICAL CHARACTERISTICS

Operating voltage	230 V 50
Contact configuration	SPDT
Temperature range	5 to 30°C
Switching current at 230V AC	6A ($\cos \varphi=1$) / 3A ($\cos \varphi =0.6$)
Switching differential	approx. 0,5 K
Sensor system	bimetal
Switches	ON / OFF
	mode of operation
	fan speed

INSTALLATION OF PIPE THERMOSTAT (CHANGE OVER)




The pipe thermostat (change-over switch) supplied in option is to be mounted on the water supply pipe.



Crimp the 6.35 F fast-on clips with their insulator bushes (supplied) on the wires of this thermostat.

THIS ACCESSORY MUST BE USED IN CONJONCTION WITH A 3-WAY



OPERATING TEMPERATURE RANGE

Opening	$30 \pm 4^\circ \text{ C}$
Closing	$15 \pm 4^\circ \text{ C}$

CONNECTION OF THE CHANGE-OVER SWITCH

Protect the wires with the flexible sheath supplied.

Wire as shown in the wiring diagram at the end of this booklet.

SEE APPENDIX

FINAL OPERATIONS



ADJUSTMENT OF THE TEMPERATURE RANGE


The room thermostat is set in the factory for a minimum temperature of +5°C and a max. temperature of +30°C.

Two rings are provided inside the knob for reducing the temperature range.

➤ Example: 12°C to 25°C

ADJUSTMENT PROCEDURE

1. Setting the temperature range
e.g. max. 25°C, min. 12°C.
2. Remove the control knob.
3. Use a pointed object to align the mark on the red ring (max. value) with the desired maximum temperature (25°C), turning the red index opposite the outside numbers counterclockwise.
4. Use a pointed object to align the mark on the blue ring (min. value) with the desired minimum temperature (12°C), turning the blue index opposite the inside numbers clockwise.
5. Install the control knob.



The temperature ranges can be graduated in:



➤ degrees Celsius °C
from 5°C to 30°C

➤ number 1 to 6
1=5°C
2=10°C
3=15°C
4=20°C
5=25°C
6=30°C

TAE20 AMBIENCE THERMOSTAT



FIELDS OF APPLICATION

- Regulating ambient temperature in rooms heated or cooled by 2 tubes convector fans with electric heating.
- Opening and closing the valve.
- Cutting in and out the electric heating.
- Controlling the three speed fan.

DESCRIPTION

The unit comprises two parts:


- A plastic case, housing the electronics, the controls and an internal ambience sensor.
- A mounting plate.

The case is hooked onto the fitted mounting plate, then click fastened.

The screw terminal connections are located on the mounting plate, with the DIP switches on the back of the case.

ADJUSTMENT AND CONTROL ELEMENTS

- 1 Operating mode switch "ON-OFF" and manual fan speed selection).
- 2 Electro-luminescent diodes for displaying the heating and cooling modes and the fan.
- 3 Minimum temperature setting limiter (adjustable by increments of 1 K). Mechanical stop accessible by removing the button 5.
- 4 Maximum temperature setting limiter (adjustable by increments of 1 K). Mechanical stop accessible by removing the button 5.
- 5 Ambient temperature setting adjustment button.
- 6 Set of DIP switches.



REFER TO SPECIAL TAE 20 ROOM THERMOSTAT MANUAL

WIRING DIAGRAM


SEE APPENDIX



A device to disconnect all the power conductors with an approved minimum opening distance must be included in the mains power supply according to best installation practices.

RESET SAFETY DEVICE

The electric heating system is equipped with **1 SAFETY DEVICES**. They cut off electrical supply to the heating resistances as soon as an operating anomaly is detected.



**APPENDIX
ANNEXE
ANLAGE
ALLEGATO
ANEXO**

APPENDIX / ANNEXE / ANLAGE / ALLEGATO / ANEXO

APPENDIX / ANNEXE / ANLAGE / ALLEGATO / ANEXO

WIRING DIAGRAM

SCHEMAS ELECTRIQUES

STROMLAUFPANS

SCHEMA ELETTRICO

ESQUEMA ELECTRICO

TAKE CARE!

These wiring diagrams are correct at the time of publication. Manufacturing changes can lead to modifications. Always refer to the diagram supplied with the product.

ATTENTION

Ces schémas sont corrects au moment de la publication. Les variantes en fabrication peuvent entraîner des modifications. Reportez-vous toujours au schéma livré avec le produit.

ACHTUNG!

Diese Stromlaufplans sind zum Zeitpunkt der Veröffentlichung gültig. In Herstellung befindliche Varianten können Änderungen mit sich bringen. In jedem Fall den mit dem Produkt gelieferten Stromlaufplan hinzuziehen.

ATTENZIONE !

Questi schemi sono corretti al momento della pubblicazione. Le varianti apportate nel corso della fabbricazione possono comportare modifiche. Far sempre riferimento allo schema fornito con il prodotto.

ATENCIÓN !

Esto esquemas son correctos en el momento de la publicación. Pero las variantes en la fabricación pueden ser motivo de modificaciones. Remítase siempre al esquema entregado con el producto.

**POWER SUPPLY MUST BE SWITCHED OFF BEFORE STARTING TO
WORK IN THE ELECTRIC CONTROL BOXES!**

**MISE HORS TENSION OBLIGATOIRE AVANT TOUTE INTERVENTION
DANS LES BOITIERS ELECTRIQUES.**



**VOR JEDEM EINGRIFF AN DEN ANSCHLUßKÄSTEN UNBEDINGT
DAS GERÄT ABSCHALTEN!**

**PRIMA DI OGNI INTERVENTO SULLE CASSETTE ELETTRICHE
ESCLUDERE TASSATIVAMENTE L'ALIMENTAZIONE !**

**PUESTA FUERA DE TNESIÓN OBLIGATORIA ANTES DE CUALQUIER
INTERVENCIÓN EN LAS CAJAS ELÉCTRICAS!**

LEGENDE

BK	BLACK	SCHWARZ	NOIR	NERO
BN	BROWN	BRAUN	BROWN	BRUNNO
BLU	BLUE	BLAU	BLEU	BLUO
BLU/BLA	GREEN/YELLOW	GRÜN/GELB	JAUNE	GRANAT
CY	CYAN	GRIS	GRIS	GRIGIO
GRIS	GREY	GRIS	GRIS	GRIGIO
ORANGE	ORANGE	ORANGE	ORANGE	ROSSO
RO	RED	ROT	ROUGE	VIOLET
WT	VIOLET	VIOLETT	VIOLET	VIOLA
WH	WHITE	WEISS	BLANC	BIANCO

LEGENDE

MV	MOTEUR VENTILATION
CV	CONDENSATEUR
SM	CHANGE-OVER
YFC	MAGNETVENTIL
X	ANSCHLUSS KLEMMLEISTE

LEGEND

MV	AIR MOTOR
CV	CAPACITOR
SM	CHANGE-OVER
YFC	4 WAYS VALVE
X1/X2	UNIT TERMINAL
X	MAIN TERMINAL STRIP

LEYENDA


MV	FAN MOTOR VENTILADOR
CV	CONDENSATOR
SM	CHANGE-OVER
YFC	ELECTROVALVULA
X1/X2	REGULACION DE CONEXIONES
X	BORNERA DE ALIMENTACION

LEGENDA

MV	MOTOR VENTILATORE
CV	CONDENSATORE
SM	CHANGE-OVER
YFC	ELETROVALVOLA
X1/X2	MORSETTERA COLLEGAMENTO
X	MORSETTERA ALIMENTAZIONE

230V ~ 50Hz	VERS THERMOSTAT
SE 3135	TO THERMOSTAT
399909	ZU RAUMTHERMOSTAT
	VIA THERMOSTATO

A THERMOSTATO




OPZIONI
OPCIONES
OPTIONEN
OPTIONS
OPTIONS

VIA TERMOSTATO: COLLEGAMENTI SECONDO LE OPZIONI
A TERMOSTATO: CABLEADO SEGUN OPCIONES
ZU RAUMTHERMOSTAT: VERBINDUNG NACH OPTIONEN
TO THERMOSTAT : WIRING ACCORDING TO OPTIONS
VERS THERMOSTAT: CABLAGE SELON OPTION

18/50

BK	NORI	BLACK	BLAU	BLUE	BRUNN	SCHWARZ	NEGRO	NEGO	BLU	BU
BU	BLAU	BLACK	BLAU	BLUE	BRUNN	SCHWARZ	NEGRO	NEGO	BLU	BU
BU	GRUNE	GREEN	GRUN	VERDE	VELLOM	GELB	MARILLO	VERDE	GRILLO	GNYE
BU	BLAU	BLACK	BLAU	BLUE	BRUNN	SCHWARZ	NEGRO	NEGO	BLU	BU
BU	WEISS	WHITE	WEISSE	BLANCO	VIOLETT	PURPLE	MARILLO	VERDE	GRILLO	GNYE
BU	BLAU	BLACK	BLAU	BLUE	BRUNN	SCHWARZ	NEGRO	NEGO	BLU	BU
BU	BLAU	BLACK	BLAU	BLUE	BRUNN	SCHWARZ	NEGRO	NEGO	BLU	BU
BU	BLAU	BLACK	BLAU	BLUE	BRUNN	SCHWARZ	NEGRO	NEGO	BLU	BU
BU	BLAU	BLACK	BLAU	BLUE	BRUNN	SCHWARZ	NEGRO	NEGO	BLU	BU
BU	BLAU	BLACK	BLAU	BLUE	BRUNN	SCHWARZ	NEGRO	NEGO	BLU	BU


SE 3133 E
CODE 399697
(LEGENDE N 710)




APPENDIX / ANNEXE / ANLAGE / ALLEGATO / ANEXO

								SCH	SW
GB	COOLING	HEATING	LOW SPEED	MEDIUM SPEED	HIGH SPEED	ELECTRIC HEATING	CONTROL VALVE	CHANGE OVER (TAE 20)	CHANGE OVER (TRM-FA TRM-VP)
F	FROID	CHAUD	PETITE VITESSE	VITESSE MOYENNE	GRANDE VITESSE	CHAUFFAGE ELECTRIQUE	VANNE DE REGULATION	CHANGE OVER (TAE 20)	CHANGE OVER (TRM-FA TRM-VP)
D	KÜHLUNG	HEIZUNG	KLEINE GESCHWINDIGKEIT	MITTLERE GESCHWINDIGKEIT	HOHE GESCHWINDIGKEIT	ELEKTROHEIZUNG	REGELVENTIL	CHANGE OVER (TAE 20)	CHANGE OVER (TRM-FA TRM-VP)
I	FREDDO	RISCALDO	BASSA VELOCITÀ	VELOCITÀ MEDIA	ALTA VELOCITÀ	RISCALDAMENTO ELETTRICO	VALVOLA DI REGOLAZIONE	CHANGE OVER (TAE 20)	CHANGE OVER (TRM-FA TRM-VP)
E	FRIO	CALOR	VELOCIDAD BAJA	VELOCIDAD MEDIA	VELOCIDAD ALTA	CALEFACCION ELECTRICA	VÁLVULA REGULADORA	CHANGE OVER (TAE 20)	CHANGE OVER (TRM-FA TRM-VP)




(+) +



(+) + SCH




APPENDIX / ANNEXE / ANLAGE / ALLEGATO / ANEXO




APPENDIX / ANNEXE / ANLAGE / ALLEGATO / ANEXO


(Snowflake) +



(Snowflake) + + SCH




(Snowflake) +




APPENDIX / ANNEXE / ANLAGE / ALLEGATO / ANEXO


 (Snow)



 (Wavy Line)




 +  (Snow + Wavy Line)




APPENDIX / ANNEXE / ANLAGE / ALLEGATO / ANEXO

 + SCH




4	N	3	2	1	6	8	7
TRM-FA							

 +



4	N	3	2	1	6	8	7
TRM-FA							






4	N	3	2	1	6	8	7
TRM-FA							

APPENDIX / ANNEXE / ANLAGE / ALLEGATO / ANEXO

()




TRM-FA

(+)

()

()



TRM-FA

APPENDIX / ANNEXE / ANLAGE / ALLEGATO / ANEXO

CE Compliance declaration

Under our own responsibility, we declare that the product designated in this manual comply with the provisions of the EEC directives listed hereafter and with the national legislation into which these directives have been transposed.

Déclaration CE de conformité

Nous déclarons sous notre responsabilité que les produits désignés dans la présente notice sont conformes aux dispositions des directives CEE énoncées ci-après et aux législations nationales les transposant.

EG-Konformitätserklärung

Wir erklären in eigener Verantwortung, dass die in der vorliegenden Beschreibung angegebenen Produkte den Bestimmungen der nachstehend erwähnten EG-Richtlinien und den nationalen Gesetzesvorschriften entsprechen, in denen diese Richtlinien umgesetzt sind.

Dichiarazione CE di conformità

Dichiariamo, assumendone la responsabilità, che i prodotti descritti nel presente manuale sono conformi alle disposizioni delle direttive CEE di cui sottose alle legislazioni nazionali che li recepiscono

Declaración CE de conformidad

Declaramos, bajo nuestra responsabilidad, que los productos designados en este manual son conformes a las disposiciones de las directivas CEE enunciadas a continuación, así como a las legislaciones nacionales que las contemplan.

XLM OG 18 - XLM OG 18 IR
REF : 7 OG 06

LOW VOLTAGE DIRECTIVE (DBT) 2006 / 95 EEC
ELECTROMAGNETIC COMPATIBILITY DIRECTIVE 89 / 336 / EEC AMENDED BY DIRECTIVE 92 / 31 EEC AND 93 / 68 / EEC
PRESSURISE EQUIPMENT DIRECTIVE (DESP) 97 / 23 / EEC
SUB-MODULE A CATEGORY I

DIRECTIVE BASSE TENSION (DBT) 2006 / 95 C.E.E.
DIRECTIVE COMPATIBILITE ELECTROMAGNETIQUE 89 / 336 / C.E.E. AMENDEE PAR DIRECTIVE 92 / 31 CEE ET 93 / 68 / CEE
DIRECTIVE DES EQUIPEMENTS SOUS PRESSION (DESP) 97 / 23 / CEE
SOUS-MODULE A CATEGORIE I

RICHTLINIE NIEDERSPANNUNG (DBT) 2006 / 95 EG
RICHTLINIE ELEKTROMAGNETISCHE VERTRÄGLICHKEIT 89 / 336 / EG ABGEÄNDERT DURCH DIE RICHTLINIE 92 / 31 / EG UND 93 / 68 / EG
RICHTLINIE FÜR AUSRÜSTUNGEN UNTER DRUCK (DESP) 97 / 23 / EG
UNTER MODUL A, KATEGORIE I

DIRETTIVA BASSA TENSIONE (DBT) 2006 / 95 CEE
DIRETTIVA COMPATIBILITA ELETTROMAGNETICA 89 / 336 / CEE ENMENDATA DALLA DIRETTIVAV 92 / 31 CEE E 93 / 68 / CEE
DIRETTIVA DEGLI IMPIANTI SOTTO PRESSIONE (DESP) 97 / 23 / CEE
SOTTOMODULO A, CATEGORIA I

DIRECTIVA BAJA TENSION (DBT) 2006 / 95 CEE
DIRECTIVA COMPATIBILIDAD ELECTROMAGNETICA 89 / 336 / CEE ENMENDADA POR LA DIRECTIVA 92 / 31 CEE Y 93 / 68 / CEE
DIRECTIVA DE LOS EQUIPOS A PRESION (DESP) 97 / 23 / CEE
BAJA MODULO A, CATEGORIA I

And that the following paragraphs of the harmonised standards have been applied.

Et que les paragraphes suivants les normes harmonisées ont été appliqués.

Und dass die folgenden Paragraphen der vereinheitlichten Normen Angewandt wurden.

E che sono stati applicati i seguenti paragrafi delle norme armonizzate.

Y que se han aplicado los siguientes apartados de las normas armonizadas.

EN 60 335-1
EN 55 014-2

EN 60-335-2-40
EN 61 000-3-2

EN 55 014-1
EN 61 000-3-3

A Tillières Sur Avre
27370 - FRANCE
Le: 04/04/2007
Franck Bailly
Quality Manager
ACE Industrie

A.C.E Marketing

1 bis, Avenue du 8 Mai 1945

Saint-Quentin-en-Yvelines

78284 GUYANCOURT Cedex - FRANCE

Tél. : +33-1 39 44 78 00

Fax : +33-1 39 44 11 55

www.airwell.com**ACE Klimatechnik GmbH**

Berner Straße 43

60437 FRANKFURT/MAIN - GERMANY

Tel. : +49-69 507 02-0

Fax : +49-69 507 02-250

www.airwell.de**Itelco-Clima Srl**

Via XXV Aprile, 29

20030 BARLASSINA (MI) - ITALY

Tel. : +39 0362 6801

Fax : +39 0362 680281

www.itelco-clima.com**Iber elco s.a.**

Ciències, 71-81,

Mòdulo 5, Polígon Pedrosa

08908 L'HOSPITALET DE LLOBREGAT

BARCELONA - ESPAÑA

Tel. : +34 (93) 264 66 00

Fax : +34 (93) 335 95 38

www.iberelco.es

As part of our ongoing product improvement programme, our products are subject to change without prior notice. Non contractual photos.

Dans un souci d'amélioration constante, nos produits peuvent être modifiés sans préavis. Photos non contractuelles.

In dem Bemühen um ständige Verbesserung können unsere Erzeugnisse ohne vorherige Ankündigung geändert werden. Fotos nicht vertraglich bindend.

A causa della politica di continua miglioria posta in atto dal costruttore, questi prodotti sono soggetti a modifiche senza alcun obbligo di preavviso. Le foto pubblicate non danno luogo ad alcun vincolo contrattuale.

Con objeto de mejorar constantemente, nuestros productos pueden ser modificados sin previo aviso. Fotos no contractuales.

**ACE**ACE - 1 bis, av. du 8 mai 1945 - Saint-Quentin-en-Yvelines
F - 78284 Guyancourt Cedex
Fax : +33 (0) 1 39 44 11 55 - Tel. : +33 (0) 1 39 44 78 00
www.airwell.com