



3 INDOOR UNIT WIRING

- CAUTION**
- Before starting work, check that power is not being supplied to indoor units and the outdoor unit.
 - Match the terminal block numbers and connection cord colors with those of the outdoor unit. Erroneous wiring may cause burning of the electric parts.
 - Connect the connection cords firmly to the terminal block. Imperfect installation may cause a fire.
 - Always fasten the outside covering of the connection cord with the cord clamp. (If the insulator is chafed, electric leakage may occur.)
 - Always connect the ground wire.




- Remove the front panel. (To remove the front panel, refer to "FRONT PANEL AND UNDER COVER REMOVAL" in this installation instruction sheet.)
- Remove the under cover.




10 FINISHING

- Insulate between pipes.
 - For rear, right, and bottom piping, overlap the connection pipe heat insulation and indoor unit pipe heat insulation and bind them with vinyl tape so that there is no gap.
 - For left and left rear piping, butt the connection pipe heat insulation and indoor unit pipe heat insulation together and bind them with and vinyl tape so that there is no gap.
- For left and left rear piping, wrap the area which accommodates the rear piping housing section with cloth tape.
- For left and left rear piping, bind the connection cord to the top of the pipe with vinyl tape.
- For left and left rear piping, bundle the piping and drain hose together by wrapping them with cloth tape over the range within which they fit into the rear piping housing section.



4 OUTDOOR UNIT INSTALLATION

- WARNING**
- Install the unit where it will not be tilted by more than 5°.
 - When installing the outdoor unit where it may be exposed to strong wind, fasten it securely.




- Set the unit on a strong stand, such as one made of concrete blocks to minimize shock and vibration.
- Do not set the unit directly on the ground because it will cause trouble.



11 POWER

- WARNING**
- The rated voltage of this product is 230 V A.C. 50 Hz.
 - Before turning on the verify that the voltage is within the 198 V to 264 V range.
 - Always use a special branch circuit and install a special receptacle to supply power to the room air conditioner.
 - Use a circuit breaker and receptacle matched to the capacity of the room air conditioner. (Fuse • breaker rating: 25 A)
 - The circuit breaker is installed in the permanent wiring. Always use a circuit that can trip all the poles of the wiring and has an isolation distance of at least 3mm between the contacts of each pole.
 - Perform wiring work in accordance with standards so that the room air conditioner can be operated safely and positively.
 - Install a leakage circuit breaker in accordance with the related laws and regulations and electric company standards.




5 CONNECTING THE PIPING

- CAUTION**
- The maximum lengths of this product are shown in Table 5-1. If the units are further apart than this, correct operation can not be guaranteed.

1. LIMITATION OF REFRIGERANT PIPING LENGTH

Table 5-1

Total max length (A+B)	30 m (98 ft)
Max length for each indoor unit (A or B)	20 m (66 ft)
Max height difference (H)	10 m (33 ft)



2. FLARING

- Cut the connection pipe to the necessary length with a pipe cutter.
- Hold the pipe downward so that cuttings will not enter the pipe and remove the burrs.
- Insert the flare nut (always use the flare nut attached to the indoor and outdoor units respectively) onto the pipe and perform the flare processing with a flare tool.




Table 5-2 Flaring dimension: B

Pipe outside diameter	B (mm)
6.35 mm (1/4 in.)	9.1
9.52 mm (3/8 in.)	13.2
12.7 mm (1/2 in.)	16.6

When using conventional flare tools to flare R410A pipes, the dimension A should be approximately 0.5 mm more than indicated in Table 5-3 (for flaring with R410A flare tools) to achieve the specified flaring. Use a thickness gauge to measure the dimension A.

Table 5-3 Pipe outside diameter

Pipe outside diameter	A (mm)
6.35 mm (1/4 in.)	0 to 0.5
9.52 mm (3/8 in.)	0 to 0.5
12.7 mm (1/2 in.)	0 to 0.5

3. BENDING

- When bending the pipe, be careful not to crush it.
- To prevent breaking of the pipe, avoid sharp bends. Bend the pipe with a radius of curvature of 70 mm or over.
- If the copper pipe is bent or pulled to often, it will become stiff. Do not bend the pipe more than three times at one place.

4. CONNECTION

- Install the outdoor unit wall cap (supplied with the optional installation set or procured at the site) to the wall pipe.
- Connect the outdoor unit and indoor unit piping.
- After matching the center of the flare surface and tightening the nut hand tight, tighten the nut to the specified tightening torque with a torque wrench. (Tighten the flare nut of the outdoor unit 3-way valve after air purging.)




Table 5-4 Flare nut tightening torque

Flare nut	Tightening torque
6.35 mm dia.	16 to 18 N·m (160 to 180 kgf·cm)
9.52 mm dia.	30 to 42 N·m (300 to 420 kgf·cm)
12.7 mm dia.	50 to 62 N·m (500 to 620 kgf·cm)

Do not remove the cap from the connection pipe before connecting the pipe.

6 VACUUM PROCESS

- CAUTION**
- Do not purge the air with refrigerants but use a vacuum pump to vacuum the installation! There is no extra refrigerant in the outdoor unit for air purging!
 - Use a vacuum pump for R410A exclusively. Using the same vacuum pump for different refrigerants may damage the vacuum pump or the unit.
 - Charging of additional refrigerant (R410A) according to the piping length is unnecessary.






1. VACUUM

- Remove the cap, and connect the gauge manifold and the vacuum pump to the charging valve by the service hoses.
- Vacuum the indoor unit and the connecting pipes until the pressure gauge indicates -0.1 MPa (-76 cmHg).
- When -0.1 MPa (-76 cmHg) is reached, operate the vacuum pump for at least 15 minutes.
- Disconnect the service hoses and fit the cap to the charging valve to the specified torque.
- Remove the blank caps, and fully open the spindles of the 2-way and 3-way valves with a hexagon wrench (Torque : 6 to 7 N·m (60 to 70 kgf·cm)).
- Tighten the blank caps of the 2-way valve and 3-way valve to the specified torque.

Tightening torque

Blank cap	20 to 25 N·m (200 to 250 kgf·cm)
Charging port cap	13 to 16 N·m (125 to 160 kgf·cm)





7 GAS LEAKAGE INSPECTION

- CAUTION**
- After connecting the piping, check the joints for gas leakage with gas leak detector.



8 RECHARGING THE REFRIGERANT




- When moving and installing the air conditioner, do not mix gas other than the specified refrigerant (R410A) inside the refrigerant cycle.
- When charging the refrigerant (R410A), always use an electronic balance for refrigerant charging (to measure the refrigerant by weight).
- When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composition is stable.
- Add refrigerant from the charging valve after the completion of the work.



- WARNING**
- Before starting work, check that power is not being supplied to the outdoor unit.
 - Match the terminal block numbers and connection cord colors with those of the indoor unit side. Erroneous wiring may cause burning of the electric parts.
 - Connect the connection cords firmly to the terminal block. Imperfect installation may cause a fire.
 - Always fasten the outside covering of the connection cord with cord clamps. (If the insulator is clamped, electric leakage may occur.)
 - Always connect the ground wire.
- CAUTION**
- The power cord is not supplied with the outdoor unit. Use 2.0 mm² to 3.5 mm² H07RN-F or equivalent as the connection cord.
 - Select power cable matched to the fuse capacity. (Install in accordance with standard.)


9 OUTDOOR UNIT WIRING

- Process the end of the connection cords to the dimension shown in (Fig. 9-2) and bend the end of each cord as shown in (Fig. 9-1).
- Connect the end of the power cord and connection cord fully into the terminal block.
- Fasten the sheath with a cord clamp.




7 GAS LEAKAGE INSPECTION

- Pass the connection cord and power cord through the hole of the 3-way valve bracket and run them to the outside of the cabinet. Do not block the ventilation slots in the cabinet when wiring the power cord and connection cords.
- Install the valve cover as shown in (Fig. 9-5). Pass the power cord and connections cords through the valve cover when wiring them.



9 OUTDOOR UNIT WIRING




13 CUSTOMER GUIDANCE

- Explain the following to the customer in accordance with the operating manual:
- Starting and stopping method, operation switching, temperature adjustment, timer, air flow switching, and other remote control unit operations.
 - Air filter removal and cleaning, and how to use the air louvers.
 - Give the operating and installation instruction sheets to the customer.

14 REMOTE CONTROL UNIT HOLDER INSTALLATION

- CAUTION**
- Check that the indoor unit correctly receives the signal from the remote control unit, then install the remote control unit holder.
 - Select the remote control unit holder selection site by paying careful attention to the following: Avoid places in direct sunlight. Select a place that will not be affected by the heat from a stove, etc.



INDOOR UNIT (12, 9 and 7 Type)

Error contents	Error display		
	OPERATION (RED)	TIMER (GREEN)	SWING (ORANGE)
Indoor unit circuit board error	○	○	○
Room temperature thermostat or piping thermostat error (wire disconnected or broken)	2 times ●	○	○
Indoor unit-outdoor unit miswiring	5 times ●	○	○
Indoor unit fan error	6 times ●	○	○

○ : Fast flashing ● : Slow flashing — : Off

CHECK ITEMS

(1) INDOOR UNIT

- Is operation of each button on the remote control unit normal?
- Does each lamp light normally?
- Do not air flow direction louvers operate normally?
- Is the drain normal?
- Is there any abnormal noise and vibration during operation?

(2) OUTDOOR UNIT

- Is there any abnormal noise and vibration during operation?
- Will noise, wind, or drain water from the unit disturb the neighbors?
- Is there any gas leakage?

- Do not operate the air conditioner in the test running state for a long time.
- For the operation method, refer to the operating manual and perform operation check.