


Compact Boiler Pump INSTRUCTIONS

In the box




Safety

- If pump fails, the safety float switch will shut off boiler operation.
- Pump suitable for boiler with heat output 85kW condensate PH value +2.7.
- Do not handle pump in wet conditions or with wet hands.
- To reduce the risk of electric shock, ensure electrical supply is permanently wired to earth.

Specification

- Inlet up to 28mm
- Tank capacity: 0.24L
- High level safety cut-out
- Outlet size: 6mm
- Maximum water temperature: 60°C
- Maximum noise level: 35 dB(A) at 1m

Installation




- If unable to create a downward slope at the highest point, an inverted U must be formed in the tubing.
- When tubing from the pump goes to a soil stack or waste pipe, always use a waste trap or a 75mm U trap formed within the tubing at the exit point.
- Where tubing from the pump goes to external soil and vent stack, extra care must be taken to prevent condensate from freezing and causing blockage.

Power Supply

- 230V AC 16W
- 1PH 50/60 Hz
- 3A alarm wires, normally closed
- Double insulated

Electrical Connections

Live:BrownNeutral:BlueSafety switch:2x BlackEarth – Yellow/Green



1 The pre-wired safety switch SHOULD ALWAYS be utilised.


• If a fused plug is used, a 3 amp fuse is recommended.

Commissioning & Maintenance

- Before servicing the pump, make sure the electrical power is disconnected at the fuse box for both the pump and boiler.
- When commissioning the pump please check for debris in the pump tank. Remove any material that might block the drain line or drain into the boiler pump.
- Regularly clean the holding tank and floats with warm water and soap. Rinse completely when finished.
- Check the inlet and outlet piping ensuring that there are no restrictions in the tubing.

Contact Aspen Pumps for further help.

Performance



For further information please visit **www.aspenpumps.com** or contact +44 (0)1323 848842

