



**WSAT-EE 17-21-25-31-41-51-61-
71-81-91-101-121-131-151**

**ELFO ENERGY COMPACT
AIR COOLED WATER CHILLER FOR OUTDOOR INSTALLATION**

Installation and Use Manual

| | |
|--|-----------|
| UNIT IDENTIFICATION | 4 |
| INSTRUCTIONS FOR THE USER | 5 |
| GENERAL WARNINGS | 7 |
| RESIDUAL RISKS | 8 |
| RECEPTION | 11 |
| INSPECTION UPON RECEPTION..... | 11 |
| STORAGE..... | 11 |
| HANDLING..... | 11 |
| POSITIONING | 12 |
| GENERAL..... | 12 |
| FUNCTIONAL CLEARANCES..... | 12 |
| POSITIONING..... | 12 |
| WATER CONNECTIONS | 14 |
| GENERAL..... | 14 |
| EXCHANGER USE SIDE..... | 14 |
| DIAGRAM OF RECOMMENDED USE SIDE CONNECTION..... | 15 |
| USE SCHEMA..... | 15 |
| ELECTRICAL CONNECTION | 16 |
| GENERAL..... | 16 |
| STANDARD UNIT ELECTRICAL DATA..... | 16 |
| CONNECTION TO THE MAINS..... | 17 |
| SYSTEM COMPOSITION..... | 17 |
| FUNCTIONAL CONNECTIONS..... | 18 |
| START-UP | 21 |
| PRELIMINARY CHECKS..... | 21 |
| REFRIGERANT SYSTEM..... | 21 |
| WATER SYSTEM..... | 21 |
| ELECTRICAL SYSTEM..... | 21 |
| VERIFy tensions – absorptions..... | 22 |
| UNIT EQUIPPED WITH SCROLL COMPRESSORS..... | 22 |
| REMOTE INPUT CONFIGURATIONS..... | 22 |
| SETTING THE SET-POINT..... | 22 |
| EVAPORATOR WATER FLOW RATE..... | 22 |
| REFRIGERANT CIRCUIT PARAMETER CHECK..... | 22 |
| CONTROL | 23 |
| OPERING MODES..... | 23 |
| CHARACTERISTICS..... | 23 |
| SET POINT..... | 24 |
| REMOTE OR SERVICE KEYPAD (OPTIONALS)..... | 26 |
| ACCESSIBLE PARAMETERS FROM REMOTE OR SERVICE KEYBOARD..... | 27 |
| PARAMETER MODIFICATION..... | 27 |
| VISIBLE STATUS FROM REMOTE KEYBOARD OR SERVICE KEYBOARD..... | 28 |
| STATUS DISPLAY..... | 28 |
| ALARMS..... | 29 |
| ROUTINE MAINTENANCE | 30 |
| SERVICES : PARTS SUBJECT TO INTERVENTION | 30 |
| MAINTENANCE INSPECTIONS..... | 31 |
| 97/23 CE PED directive..... | 31 |
| PUT AT REST..... | 31 |
| REFRIGERANT TABLES..... | 32 |
| TROUBLESHOOTING | 33 |
| DECOMMISSIONING OF THE UNIT | 35 |
| DISCONNECTING THE UNIT..... | 35 |
| DISMANTLING AND DISPOSAL..... | 35 |
| DIMENSIONS | 37 |
| TECHNICAL DATA | 43 |

UNIT IDENTIFICATION

SERIAL NUMBER LABEL

The units are identified by the serial number label shown here.

The label lists the type of unit (series and size), serial number, year of manufacture, number of electrical diagram, main technical data, logo and address of the manufacturer.

The label is placed on the unit, generally near the electrical panel and also on the external panelling.

IT MUST NEVER BE REMOVED.

SERIAL NUMBER

This provides unique identification of the machine. It makes it possible to trace the specific features of the unit and to identify the components installed in it.

Without this number, it is not possible to identify with certainty the spare parts that are specific to that unit.

When requesting assistance, always provide the type of machine and the serial number.

Write them in the space below so that they are readily available when needed.

Type of unit : _____

Serial number : _____

Wiring diagram : _____

Year of manufacture : _____

| | |
|---|---|
| <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px dashed black; padding: 5px; font-weight: bold; font-size: 1.2em;">LOGO</div> <div style="font-size: 2em; font-weight: bold;">CE</div> </div> | |
| <small>TIPO TYPE/TYP TYPE/TIPO</small> | |
| <small>NUMERO MATRICOLA SERIAL NUMBER / SERIENNUMMER NUMERO DE SERIE / NUMERO DE SERIE</small> | |
| <small>ANNO DI FABBRICAZIONE YEAR OF MANUFACTURE / BAUJAHR ANNEE DE FABRICATION/AÑO DE FABRICACIÓN</small> | |
| <small>REFRIGERANTE REFRIGERANT / KÄLTEMITTEL REFRIGERANT / REFRIGERANTE</small> | <small>GRUPPO (PED) GROUP / GRUPPE GROUPE / GRUPO</small> |
| <small>CARICA REFRIGERANTE REFRIG. CHARGE / KÄLTEMITTELFÜLLUNG CHARGE REFRIG./CARGA REFRIG.</small> | |
| | <small>Kg</small> |
| <small>TENSIONE VOLTAGE / SPANNUNG TENSION / TENSION</small> | |
| | <small>V/Ph/Hz</small> |
| <small>F.L.A.</small> | |
| | <small>A</small> |
| <small>F.L.I.</small> | |
| | <small>kW</small> |
| <small>SCHEMA ELETTRICO WIRING DIAGRAM / SCHALTPLAN SCHEMA ELECTRIQUE/ESQUEMA ELÉCTRICO</small> | |
| | <small>N°</small> |
| <small>PRESSIONE MASSIMA ESERCIZIO MAX OPERATING PRESS. / MAX BETRIEBSDRUCK PRESS. DE SERVICE MAX/PRESION DE EJERCICIO MÁX</small> | |
| | <small>bar</small> |
| <small>CATEGORIA PED PED CATEGORY / PED KATEGORIE CATEGORIE PED / CATEGORIA PED</small> | |
| | <small>PS H/L bar</small> |
| <small>TEMP. LATO BP TEMPERATURE ON LP SIDE / TEMP. ND-SEITE TEMP. COTE BP / TEMP. PARTE BP</small> | |
| | <small>°C</small> |
| <small>INDIRIZZO / ADDRESS / ADRESSE / ADRESSE / DIRECCIÓN</small> | |


INSTRUCTIONS FOR THE USER

- **This is a partial sintex of the information provided in the manual; carefully read this manual**
- Carefully read this manual. Keep it with the electrical diagram. Make it available to technicians for servicing.
- Ask the installer for training on start-up, shutdown, changing set points, placing in at-rest status, maintenance, what to do or not to do in the event of a breakdown.
- Provide for scheduled maintenance by specialized technicians so as to ensure long-lasting operation of the unit.
- If you expect the machine to be shut down for long periods of time, disconnect the electrical power supply. In winter, take necessary measures to deal with possible freezing (unit and system pipes) .

PRINCIPLE OF OPERATION

SUMMER: the cooling cycle allows the transfer of excess indoor heat to the external environment.


1. The compressor compresses the refrigerant gas, placing it at high pressure and high temperature.
2. In the external coil, the refrigerant is cooled, and the heat is released into the environment by means of the fan. This is why the coil needs to be kept clean and free of obstacles.
3. When it cools, the refrigerant becomes liquid.
4. The expansion valve causes a sudden drop in the pressure of the refrigerant, which becomes very cold as its volume increases.
5. In the exchanger, the refrigerant evaporates and absorbs the heat from the water that returns to the system, cooling it.



WATER CIRCUIT






The diagram on the side is indicative and includes optional components; check with the installer about the system configuration used.

1. fan coil heating;
2. if the room needs to be heated, the 3-way valve diverts the water towards the underfloor piping (all or in part); if instead the underfloor piping is satisfied, it returns the water directly to the unit;
3. the pump keeps the water in circulation in the underfloor piping
4. underfloor heating
5. the pump returns the water to the unit



TO DO FOR:

Some functions are active only if they are enabled during installation (remote ON-OFF, remote SUMMER WINTER change, remote ECO, domestic hot water, set point compensation). Check with the installer about the configuration used.

| | | |
|---|--|---|
| Start the unit | LONG pressing of the ON/OFF button |  |
| Choose the SUMMER mode possible also by external enabling (see ELECTRICAL CONNECTIONS) | “SUN” button Green led on |  |
| Limit the energetic consumption Control by external enabling (see ELECTRICAL CONNECTIONS) | ECO button |  |
| Choose the optimal comfort level | COMFORT button |  |
| Minimize the consumptions maintaining the system at a safety temperature in SUMMER (MAINTENANCE function) | Put the unit in OFF (parameter 44 must be = 1) yellow led is flashing |  |
| Identify the cause of the unit shutdown | RED LED lit - flashing: the alarm resets automatically - on continuously: a manual reset is necessary | |



ELECTRICAL CIRCUIT ALARM

Inlet probe
 Outlet probe
 Radiant panel water probe
 Coil/flow probe
 External probe
 Pressure 1 probe
 Water reset inlet
 External relative humidity probe
 Phase monitor
 Electric heater output probe

serial faulty alarm



REFRIGERANT CIRCUIT ALARM



HP
 LP
 CCMP/VENT
 HP1 Pre-Alarm
 BP1 Pre-Alarm

serial faulty alarm



WATER CIRCUIT ALARM

Flow pump
 System charged with water
 Antifreeze alarm
 Antifreeze PREAlarm
 Pump alarm
 C1 PREAlarm
 PRad. Cooling limit alarm
 PRad. Water frost alarm
 Coil frost alarm
 Alarm ?T° incongruous
 Electric heater antifreeze alarm
 serial faulty alarm

| | | |
|---|---|---|
| To reset the current alarm ONLY AFTER THE CAUSE ELIMINATION ! | TEST + ON/OFF contemporary for some seconds |  |
| Modify the water temp. in COOLING | Control parameter ametro 32 | Only by SERVICE keypad  |
| Modify the water temp. in ECO cooling | Control parameter 29 | |
| Modify the water temp. in MAINTENANCE cooling | Control parameter 42 | |

COMMON CAUSES OF SHUTDOWN

1. coils dirty - clogged by leaves - nearby obstacles - covered with snow
2. set point too low (in summer) or too high (in winter)
3. water in system is too hot (in summer, for example with machine left off over the weekend) or too cold (in winter)
4. water filter dirty
5. external permissions (remote ON-OFF etc.)
6. water cut-off valves closed
7. system not pressurized - air needs to be vented
8. circulator pump not running (after seasonal shutdown)
9. unit exchanger dirty

GENERAL WARNINGS

MANUAL PURPOSE

This manual has been designed to enable the unit to be installed, started up and maintained correctly.

MANUAL INSTRUCTIONS

It is essential to observe these instructions.

The manufacturer declines all liability for any damage that may be caused whether directly or indirectly to persons or things if these instructions are not heeded.

MANUAL STORAGE

This manual and the unit's wiring diagram should be carefully stored so that they are readily available to the operator when required.

EXPERT PERSONAL

The unit must be installed, tested and maintained by expert personal who meet the relevant legal requirements (Italian law No. 46 of 5/3/1990).

LOCAL SAFETY REGULATION INSTALLATION

The installation must be performed observing the local safety regulations.

POWER SUPPLY

Make sure the power supply conforms to the data on the unit's rating plate, located inside the door of the main electrical panel.

PACKAGING

The packaging material (plastic bags, polystyrene foam, nails, etc.) is potentially dangerous and should therefore be kept away from children and recycled in compliance with the local regulations in force.

MAINTENANCE

Before performing any service operations, cut off the power. Perform the operations in conformity with the local regulations in force.

PERIODICAL INSPECTIONS

Perform periodical inspections to locate possible loosened or broken parts. If the repairs are not performed, there will be a higher risk for things and peoples to become damaged and injured.

FAULT – POOR OPERATION

Switch off the unit in the event of faults or poor operation.

REPAIR

Only have repairs carried out by a service centre authorised by the manufacturer, and insist on the use of original spare parts only.

Failure to comply with the above may compromise the safety of the unit.

MODIFICATIONS

The manufacturer will not accept any responsibility, and the warranty will lapse, in the event of electric and/or mechanical modifications. Any modification which is not formally authorized, and which does not respect the instructions given in this manual, will cause the warranty to lapse.

INTENDED USE

The unit must only be used for the specific purpose it was designed :

The unit is designed to cool water or a water and glycol mix for air-conditioning, within the limits defined in the technical bulletin and this manual.

Any use other than that specified does not imply any commitment or constraint by the manufacturer in any way whatsoever.

ADDITIONAL SAFETY PRECAUTIONS

This unit has been especially designed and manufactured so to prevent any risk to persons and health hazard.

For this reason, design solutions fit to eliminate (where possible) any cause of risk and sensibly reduce the probability of danger have been adopted.

Please refer to the "Residual Risks" section of this manual and strictly observe the behaviour prescriptions listed there in order to prevent any possible risk that hasn't been possible to avoid in the design stage.

DATA UPDATING

The manufacturer may be able to modify the data without prior notice as a consequence of constant improvements.

REGULATIONS AND CERTIFICATIONS

UNI EN ISO 9001 CERTIFICATION

Clivet S.p.A., in order to guarantee customer satisfaction, has chosen the ISO 9001 Quality System as the reference for all its business activities. This is demonstrated by the company's commitment to ongoing improvements in the quality and reliability of its products; its sales, design, purchasing, production and after-sales service activities are the means used to reach such purpose.

CE MARK



Clivet products bear the CE mark, in compliance with the requirements of the following EC directives, including the latest amendments, and with the corresponding national approximated legislation:

- - 98/37/CE
- - 89/336/CEE as modified by the directives 92/31/CEE and 93/68/CEE
- - 73/23/CEE as modified by the directive 93/68/CEE
- - 97/23/CE

EUROVENT CERTIFICATION



Clivet is participating in the EUROVENT Certification Programme "Liquid Chilling Packages". Products are listed in the EUROVENT Directory of Certified Products and in the site www.eurovent-certification.com. Eurovent Chillers Certification Programme covers air cooled packaged chillers up to 600 kW and water cooled packaged chillers up to 1500 kW.

RESIDUAL RISKS


GENERAL

This section lists some of the more common situations which, being beyond the control of the manufacturer, could be a source of risk to persons or property.

DANGER AREA

The figure below highlights the area in which only authorised personnel may operate.

- **External danger zone**, identified by a precise area around the unit and its vertical projection on the ground in the case of hanging unit.
- **Internal danger zone**, identified by the area that can be entered only after having intentionally removed the protecting panels or parts of these.



A = 1000mm B = 1000mm
C = 1000mm D = 1000mm

HANDLING

If handling operations are undertaken without adopting all the necessary safety procedures and exercising due care, the unit can fall or topple, causing damage — possibly extremely serious — to persons and/or property, and to the unit itself.

Ensure the unit is handled and manoeuvred as directed on the packing and in the present manual, and in accordance with local regulations.

In the event of refrigerant gas escaping, refer to the “Safety datasheet” for the particular refrigerant.

INSTALLATION

Incorrect installation of the unit can result in water leaks, accumulation of condensate, escape of refrigerant, electric shocks, fire, as well as irregular operation or damage to the unit itself.

Make certain that the installation is carried out only by a qualified technician, also that the directions contained in this manual are followed and local statutory regulations observed.

In the event of the unit being installed in a site where there is even the slightest risk of inflammable gas escapes and consequently the possibility of such gases accumulating in area around the unit, the risk of explosion and fire cannot be discounted.

Take every care and precaution when selecting the installation site.

Installation on a structure not able to bear the weight and/or afford a secure anchorage of the equipment may cause the unit to fall and/or topple, resulting in damage to persons or property, or to the unit itself. Make certain that every care

and precaution is taken when positioning and securing the unit.

If the unit is easily accessible to children, unauthorized persons or animals, this is a situation that can give rise to accidents and injuries, perhaps serious. Install the unit in a place where access is allowed only to authorized persons, or install barriers or guards preventing unauthorized entry.

GENERAL RISKS

A smell of burning, smoke or other indications of serious irregularity could signal the onset of situations liable to cause damage to persons or property or to the unit itself. Isolate the unit from the electrical power supply (red-and-yellow) switch.

Contact an authorized service centre so that the source of the problem can be identified and remedied.

Accidental contact with heat exchange coils, compressors, pressure pipelines or other components can result in wounding or burns, or both.

Always wear suitable clothing, including protective gloves, when working in the danger area.

Maintenance or repairs carried out by unskilled operatives can result in harm or damage to persons and property, or to the unit itself. Always contact an authorized service centre.

Failure to close the panels of the unit, or to check that all the fixing screws of the panels are properly tightened, can result in harm or damage to persons or property, or to the unit itself.

Verify periodically that all panels are closed and made properly secure.

In the event of fire, the temperature of the refrigerant can rise to the point that pressure will exceed safety levels and perhaps cause fluid to be projected. It may also happen that parts of the circuit isolated by closed valves will explode.

Do not stand near safety valves, and never leave the valves of the refrigerant circuit closed.

ELECTRICAL SYSTEM

If the power line connecting the unit to the a.c. supply is incomplete, or if the connection is made with cables of incorrect cross section and/or with insufficiently rated protective devices, this can result in electric shock, toxicity hazard, damage to the unit or fire.

All work on the electrical system should be carried out referring to the wiring diagram and to the directions given in this manual, and the system itself must be dedicated.

Failure to secure the cover enclosing electrical components can lead to the infiltration of dust and water, ultimately causing electric shocks, damage to the unit, or fire.

Always fasten the cover securely to the unit.

If live metal parts of the unit are not connected properly to the earth system, they can cause electric shock or even death by electrocution.

Make absolutely certain that the connection to the earth system is made in accordance with correct practice.

Contact with live parts rendered accessible internally of the unit when the guards are removed can result in electric shock, burns or death by electrocution.

Before exposing these parts, make certain the isolating switch on the power line to the unit is set to the OFF position and padlocked, and post a warning sign.

Contact with parts that could become live when the unit is started up can result in electric shock, burns or death by electrocution.

When there is no need for circuits to be powered up, set the isolating switch on the power line to the OFF position, padlock it and post a warning sign.

MOVING PARTS

Contact with the fan rotors can cause injury.

Before removing the protective grilles or the fans themselves, make certain the isolating switch on the power line to the unit is set to the OFF position and padlocked, and post a warning sign.

Before removing the protective grilles or the fans themselves, make certain the isolating switch on the power line to the unit is set to the OFF position and padlocked, and post a warning sign.

REFRIGERANT

In the event of safety valves coming into operation and releasing refrigerant gas, persons in the vicinity can be

injured or suffer toxic effects. Always wear suitable clothing and protective goggles when working in potential hazard areas.

In the event of refrigerant gas escaping, refer to the "Safety datasheet" for the particular refrigerant.

If an open flame or heat source is brought into contact with the refrigerant, or the pressurized gas circuit should overheat (e.g. during welding operations), this can cause explosion or fire. Do not position any heat source within the hazard area.

Maintenance or repair operations involving welding must be carried out with the system emptied of refrigerant.

WATER SYSTEM

Defects affecting pipelines, connections or valves and other control componentry can result in water being leaked or sprayed from the system, occasioning damage to property or causing short circuits in the unit.

Make certain all hydraulic connections are securely made, following the directions given in the present manual.

REFRIGERANT SAFETY CHARGE

| | | R-410A |
|----|--|---|
| 01 | Identification of the product and of the supplier | Chart No FRIG 8 Product R-410A Identification of the supplier. See heading or bottom of page. No of emergency telephone. See heading or bottom of page. |
| 02 | Composition / information on ingredients | Substance/ Compound . Compound Elements / Impurities. It contains the following elements Difluorometan (R32) 50 % in weight Pentafluoroetan (R125) 50 % in weight CEE No Non applicable for mixtures. Commercial name / |
| 03 | Hazard identification | Hazard identification. Liquefied gas. Vapours are heavier than air and can cause choking by reducing the oxygen available for breathing. A rapid evaporation of the liquid can cause freezing. It can cause cardiac arrhythmia. |
| 04 | First aid measures | Inhalation. Do not administer anything to fainted people. Take to open air. Administer oxygen or practice artificial breathing if necessary. Do not administer adrenaline or similar substances. Contact with eyes. Rinse carefully with plenty of water for at least 15 minutes and consult a doctor. Contact with the skin. Rinse immediately with plenty of water. Immediately take off all contaminated cloths. Ingestion. Way of exposure not very probable. |
| 05 | Anti-fire measures | Specific hazards. Pressure increase. Dangerous combustible products. Halogen acids, traces of carbonyl halogens. Extinction means. You can use all extinction means available. Special methods. Cool the containers/tanks with sprays of water. Special protection means. In close spaces, use the self-breather. |
| 06 | Measures against the accidental leakages of the product. | Personal protections. Evacuate the personnel in safety areas. Foresee adequate ventilation. Use means of personal protection. Protection for the environment. It evaporates. Methods for eliminating the product. It evaporates. |
| 07 | Handling and stocking. | Handling and stocking. Assure a sufficient exchange of air and/or a suction system in work areas. Use only in well-ventilated rooms. Do not breathe vapours or aerosols. Carefully close the containers and keep them in a cool, dry and well-ventilated place. Keep in the original containers. Incompatible products. Explosives, inflammable materials, organic peroxides. |
| 08 | Check of the exposition / personal protection | Personal protection. Assure adequate ventilation, especially in closed rooms. Control parameters. Difluorometan (R32): Recommended limits of exposition: AEL (8h and 12h TWA) = 1000 ml/m3 Pentafluoroetan (R125): Recommended limits of exposition: AEL (8h and 12h TWA) = 1000 ml/m3 Protection of respiratory tract. For the rescue and for service work in the tanks, use an autonomous breather. Vapours are heavier than the air and can cause choking by reducing the oxygen available for breathing. Protection for the eyes. Total protection glasses. Protection for the hands. Rubber gloves. Hygienic measures. Do not smoke. |

| | | |
|----|-----------------------------------|--|
| 09 | Chemical -physical properties. | Relative density, gas (air=1) Heavier than air. Solubility in water (mg/l). Not known, but probably very low. Aspect. Colourless liquefied gas. Smell. Simile to ether. Point of ignition. Don't ignite. |
| 10 | Stability and reactivity. | Stability and reactivity. No decomposition if used following the instructions. Materials to avoid. Alkaline metals, earth alkaline metals, granulated metal salts, Al, Zn, Be etc. in powder. Dangerous decomposition products. Halogen acids, traces of carbonyl halogens. |
| 11 | Toxicological information | Local effects. Concentration substantially above the TLV value (1000 ppm) can cause narcotic effects. Inhalation of products at high concentration decomposition can cause respiratory insufficiency (pulmonary edema). Long-term toxicity. It has shown no carcinogenic, teratogen or mutagenic effects on animal experiments. Specific effects. A rapid evaporation of the liquid can cause freezing. It can cause cardiac arrhythmia. |
| 12 | Ecological information | Effects connected to ecotoxicity Pentafluoroetan (R125) Potential of global heating of halocarbides; HGWP; (R-11 = 1) = 0.84 Potential of ozone impoverishment; ODP; (R-11 = 1) = 0 |
| 13 | Disposal considerations | General considerations. Do not drain where the accumulation can be dangerous Usable as reconditioning. Depressurized containers should be given back to the supplier. Contact the supplier if the use of instructions is necessary. |
| 14 | Transport information | Designation for the transport LIQUEFIED GAS N.A.S (DIFLUOROMETAN, PENTAFLUOROETAN) UN No 3163 Class/Div 2.2 ADR /RID Nr 2, 2°A No hazard ADR/RID 20 ADR Label. Label 2: not toxic gas not inflammable. CEPIC Groupcard 20g39 - A Other information for the transport. Avoid the transport on vehicles where the loading zone is not separated from the driver compartment. Verify that the driver is informed on the potential risk of the load and that he knows what to do in case of an accident or emergency. Before starting the transport, verify that the load is well fixed and: Verify that the container valve is closed and does not leak Verify that the blind cap of the valve, if supplied, is correctly assembled. Verify that the cap (if supplied) is well assembled and that there is adequate ventilation Verify that the norms in force are respected. |
| 15 | Information on the norms in force | The product must be labelled according to the 1999/45/CE normative. Observe the following norms, the relevant updating and the applicable modifications: Circulars no.46/79 and 61/81 of the Work Ministry: risks connected to the use of products containing aromatic amines. Law Decree no. 133/92 : Norms relevant to the draining of dangerous substances in water Law Decree no. 277/91: Protection of workers for noise, lead and amianthus Law 256/74, Ministerial Decree of 28th Jan. 1992, Legislative Decree no 52 of 3rd Feb. 1997, Ministerial Decree of 28 th Apr. 1997 and following modifications: Classification, packaging and labelling of compounds and dangerous substances Decree of the Republic President no.175/88, following modifications and updating: Activities with risks of serious accidents (Seveso Law) Decree of the Republic President no 203/88: Emissions in the atmosphere Decree of the Republic President no.303/56: Hygiene of work Decree of the Republic President no.547/55: Norms concerning the accident prevention Legislative Decree. No.152 of 11th May 1999: Protection of waters. |
| 16 | Other information | Suggested uses. Refrigerant. High concentrations can cause asphyxia. Keep in a dry and well-ventilated place. Do not breathe in the gas. The asphyxia risk is often under-evaluated and must be put into evidence during the operator's training. |

Verify that all national and regional regulations are observed.
Before using this product in any new process or experiment, a deep study about the safety and the product compatibility with the materials must be performed.
The above information is based on our present know-how and describes the product considering the safety needs. However, they do not represent a guarantee and a warranty of the qualities in a juridical sense. Everyone is personally responsible for the observation of these norms.
Information present in this document is valid at the time of printing. The company is not responsible for any damages caused by the incorrect use of the product and/or for the use in conditions different from the conditions suggested.

RECEPTION

INSPECTION UPON RECEPTION

Check on arrival that the unit has not suffered damage during transit and that it is complete in every part as specified in the order. In the event of visible damage/deficiencies being discovered, make a note immediately on the delivery document with the comment: **CONDITIONAL ACCEPTANCE — CLEAR EVIDENCE OF DEFICIENCIES/DAMAGE DURING TRANSIT**

Inform both the supplier and the carrier of the details by fax and by registered mail with advice of receipt not later than 8 days after taking consignment. Notifications sent after 8 days have elapsed will be ignored.

STORAGE

Shelter from: direct sunlight, rain, sand and wind

Temperature: maximum 60°C minimum -10°C

Maximum humidity: 90%

The respect of the instructions on the exterior side of the packaging assures the physical and functional integrity of the unit for the final user's advantage.

It is recommended to:

- Handle carefully
- Keep in a dry place
- Avoid putting other objects on top of the unit (respect the limits of levels of superimposition shown in the package)
- Avoid placing the unit with thermoretractable protection under the sun since the pressure of the circuits can assume values which activate the safety valves.

HANDLING

The operation of handling the unit must be carried out respecting the instructions of the safety norms in force (Legislative Decree 626/94 and following modifications)




Before starting the handling operations:

- Value the critical points during handling (stairs, flights, disconnected routes, doors, etc)
- Verify that the lifting capacity of the means used is adequate to the unit weight
- Consider that the barycentre could be moved with respect to the center of the unit
- Before starting to lift, verify that the unit is at a stable balance

The following examples are indications; the choice of the means and of the handling modes will depend on factors, such as:

- The unit weight
- Type and overall dimensions of the unit
- Place and route for the handling (dirt yard, asphalted square, etc)
- Condition of the place of destination (roof, square, etc)
- Handling distance characteristics (distances, flights, steps, doors)

LABELS / YELLOW BRACKETS SHOW THE LIFTING POINTS



REMOVING THE PACKING

For removing the packaging, use specific personal protection for the operator (gloves, glasses, etc.).

While removing the packaging, pay attention not to damage the unit.

Check for any visible damage.

Dispose of the packaging by taking it to specialist collection or recycling centres in accordance with local regulations.

POSITIONING

GENERAL

For installing air-conditioning systems, it is necessary to consider the following:

- the technical spaces necessary for the machine and system
- the place where the machine will be installed
- the transport of thermal carrier fluids and relevant connections to the unit:
 - water
 - air
 - refrigerant (unit in more sections)
- electrical connections

If these aspects are not evaluated carefully, they can affect the performances and the working life of the unit.

FUNCTIONAL CLEARANCES

When placing the unit, please respect the functional clearances indicated in DIMENSIONS section.

The functional spaces need to be observed because of the following:

- to guarantee the good operation of the unit
- to allow the performance of all maintenance operations
- to protect the authorized operators and exposed people

If more units are placed close to one another, the functional spaces must be doubled.

POSITIONING

1. The units are designed for **OUTDOOR** installations, performed in fixed positions and in areas accessible only to qualified and authorized personnel
2. **SAFETY VALVE** (only if present on the unit) : the installer is responsible for evaluating the opportunity of installing drain tubes, in conformity with the local regulations in force (EN 378)
3. Install the unit **raised** from the ground
4. avoid installations in places subject to **flooding**
5. Consider the maximum level which can be reached by **snow**
6. Verify that the fixing/supporting points are level and suitable to support the **weight of the unit** (see the weight and the weights distribution)
7. It is recommended to put the unit on specific **antivibration devices**

Each support point of the unit sustains a different weight. Therefore, each anti-vibration device is sized for a specific support point, and can only be placed there. The anti-vibration devices must therefore be placed in accordance with the instructions provided with them and with the dimensional drawings in which the support points are indicated by W1 , W2 , W3 etc .



On each anti-vibration device (if provided by CLIVET), its identifying code is stamped, for example C6100100

Flexible joints are necessary on all the hydraulic/aerualic connections (the joints are not supplied by Clivet)



8. **Anchor** the unit to the ground; foresee windbreak barriers in case of places where there are strong prevalent winds .
9. The choice of the location of the unit is of fundamental importance for correct operation; to avoid:
 - **obstacles** that block the flow of air
 - difficulty in air **circulation**
 - **leaves** or other objects that may block the exchanger coils
 - **winds** that contrast or excessively assist the air flow
 - phenomena of **stratification** or air **re-circulation**
 - nearby **sources** of heat (chemney, extractor ecc)
 - positioning under the round level or near very high walls

The previous situations cause working anomalies or stop the machine and cause:


- during **SUMMER** operation, increase of the condensation pressure with the decay of performances and possible stops due to high pressure.





Install the unit raised off the ground and on a sturdy base.




Consider the maximum depth that snowfall might reach.



Consider clearances and direction of expelled air.




Keep the coil clean. Avoid zones with leaves / dirt / corrosives.



1. elastic joint
2. floating floor
3. soundproofing

Prevent the transmission of vibrations.



Provide windbreaks in locations with strong winds

WATER CONNECTIONS

GENERAL

Piping must be designed with the least possible number of bends and head variations. If the pressure chute of the installation is above the useful prevalence of the pump, the water delivery capacity is reduced as well as, as a consequence, the thermal exchange and the yield.

INTERCEPTING VALVES

Install on the input and output of the user parts (exchangers, coils, humidifiers, etc) So that it will be possible to carry out all the service operations and possible substitutions without emptying the installation.

PRESSURE AND TEMPERATURE INDICATOR

Install on the input and output of the user parts (exchangers, coils, humidifiers, etc) So that it will be possible to carry out all the service operations.

AUTOMATIC OR MANUAL ESCAPE VALVES

Install the highest points of tubes in a way that the air can escape from the circuit.

BLEEDING COCK

Install them at the lowest points of the circuit, so as to allow emptying.

LEAKAGE TESTS

Before performing the insulation of the tubes, carry out a leakage test.

TUBE INSULATION

All tubes of water must be insulated so that to avoid the formation of condensation and thermal dispersions along the tubes themselves. Verify that the insulation is the vapour coil type. The connections for the air escape and for the emptying must be out of the insulating thickness to assure the accessibility.

CONNECTIONS SUPPORTS

The weight of the hydraulic connections must be supported in the exterior of the unit so as not to stress the connections of user devices (exchangers, coils, humidifiers, etc) .

ANTI-VIBRATION DEVICES

In case of units with anti-vibration devices, it is necessary to assemble elastic joints, even on water connections.

RISK OF FREEZE

If the unit and the relevant water connections are subject to temperatures near 0°C:

- mix the water of the system with glycol
- protect the tubes with heating cables under the tubes insulation
- empty the system by verifying that:
 - no taps are closed so they can not trap the water, even after emptying
 - there are no low points where the water can stagnate even after emptying; blow if necessary

INSTALLATION EMPTYING

The refilling of the water present in the installation increase the oxidation phenomena and lime deposits.

If necessary empty only the interested system section and anyway empty or refill the installation if necessary .

EXPANSION TANK

The installation must be kept at the right pressure by both an expansion tank and a combined valve of pressure reduction and discharge; if the components are present on the unit, they must be installed on the installation. The expansion tank must be dimensioned in function of the water in the installation.

ARIES EFFECTS AND AIR BUBBLES CAN PRODUCE THE OVERCOMING AND CAUSE WATER DROPS.

EXCHANGER USE SIDE

FILTER

It is very important for the water to be free of impurities. If it is not, the efficiency of thermal exchange is diminished. In worst cases, the exchanger can be irreparably damaged. If the filter is not present on the machine, it must be immediately installed upstream from the unit, in a position which can be easily reached for cleaning.

The filter mesh must be :

- < 1 mm unit with 1 compressor
- < 1.5 mm multicompressor unit.

FLOW SWITCH

The flow switch must be present as a component of the system, so as to ensure shutdown of the unit if water is not circulating. It must be installed in a straight tract of the tubes, not near the elbows, which can generate harmful turbulence

UNFREEZABLE LIQUIDS

If the unit is used when the water temperature is lower than + 4°C, avoid the formation of ice by using unfreezable liquids (ex. Ethilenic Glycol) in the necessary percentage. The use must also be determined for ambient temperatures near 0°C .

ANTIFREEZE RESISTANCES

If the unit is equipped with antifreeze resistances on the exchanger side (standard or optional according to the models), verify that they are electrically fed during periods that the machine is stopped (night, weekends, long stops)


WASHING THE SYSTEM

Carefully wash the system by using clean water and discharge it before connecting the unit.

DIAGRAM OF RECOMMENDED USE SIDE CONNECTION


Depending on the type of machine and the selected setup, some components may be integrated into the unit.
The accumulation tank is necessary in the event of the following:

- the water in the system is very low
- the unit will not be used in a private house (in an industrial process or other)



1. Charged system pressure switch
2. vent
3. circulating pump / pump
4. expansion tank
5. safety valve
6. flow switch
7. pressure switch / thermometer
8. filter
9. filling valve
10. antivibration joints
11. user side exchanger
12. Differential pressure switch
13. Discharge cock
14. inertial storage tank

USE SCHEMA



1. Heating integration
2. fancoil
3. 3-ways radiant panels
4. radiant pump
5. pump / circulating pump

for more details see the ELECTRICAL DATA section

ELECTRICAL CONNECTION

GENERAL

The characteristics of the electrical lines and relevant components must be determined by **SPECIALIZED PERSONNEL ABLE TO DESIGN ELECTRICAL INSTALLATIONS**; moreover, the lines must be in conformity with professional procedures and the regulations in force.

All electrical operations should be performed by trained **PERSONNEL HAVING THE NECESSARY REQUISITES UNDER LAW** and being informed about the risks relevant to these activities.

Before performing any operation on the electrical system, make sure that the unit supply line is **SELECTED AT START**.

The earth connection must be made prior to other electrical connections.

For all electrical type operations, **REFER TO THE ELECTRICAL DIAGRAM ATTACHED TO THE UNIT**; the number of the diagram is shown on the registration plate positioned on the electrical board or next to it.

The electrical diagram should be carefully kept together with this manual and should be **AVAILABLE FOR FUTURE INTERVENTION ON THE UNIT**.

LINE OF UNIT POWER SUPPLY

The **ELECTRICAL DATA OF THE UNIT** are shown in the technical chart of this manual and on the unit registration plate. The presence of accessories can vary according to

the unit; the electrical data shown in the technical chart refer to standard units. In the event of differences between the data of the registration plate and the data shown in this manual, as well as in the technical chart, please refer to the **DATA SHOWN IN THE REGISTRATION PLATE**.

The protection device of the unit power supply line should break off the short circuit power whose value should be determined according to the plant features.

The section of supply cables and protection cable must be seized according to the characteristics of the protections used.

SIGNALS / DATA LINES

Do not overpass the maximum power allowed, which varies, according to the type of signal.

Lay the cables far from power cables or cables having a different tension and that are able to emit electromagnetic disturbances.

Do not lay the cable near devices which can generate electromagnetic interferences.

Do not lay the cables parallel to other cables; cable crossings are possible, only if laid at 90°.

Connect the screen to the ground, only if there are no disturbances

Assure the continuity of the screen during the entire extension of the cable.

Observe, if any, the requirements about impedance, capacity, attenuation.

STANDARD UNIT ELECTRICAL DATA

Voltage: 230/1/50

| Size | | | 17 | 21 | 25 | 31 | 41 | 51 |
|---|----|--|-------|-------|-------|-------|-------|--------|
| F.L.A. - FULL LOAD CURRENT AT MAX ADMISSIBLE CONDITIONS | | | | | | | | |
| F.L.A. - Pump | A | | 0.95 | 0.95 | 0.95 | 1.18 | 1.18 | 1.18 |
| F.L.A. - Total | A | | 11.82 | 14.77 | 15.44 | 20.66 | 24.46 | 32.06 |
| L.R.A. LOCKED ROTOR AMPERES | | | | | | | | |
| L.R.A. - Compressor 1 | A | | 43 | 62 | 62 | 88 | 97 | 130 |
| F.L.I. FULL LOAD POWER INPUT AT MAX ADMISSIBLE CONDITION | | | | | | | | |
| F.L.I. - Pump | kW | | 0.2 | 0.2 | 0.2 | 0.27 | 0.27 | 0.27 |
| F.L.I. - Total | kW | | 2.58 | 3.19 | 3.34 | 4.74 | 5.02 | 6.03 |
| M.I.C. MAXIMUM INRUSH CURRENT | | | | | | | | |
| M.I.C. - Value | A | | 44.49 | 63.49 | 63.49 | 90.26 | 99.26 | 132.26 |

power supply 230/1/50 Hz +/-6%

The pump is included in the total values calculation for non standard voltage please contact Clivet technical office

The units are compliant with the provisions of European standards CEI EN 60204 and CEI EN 60335.

Voltage: 400/3/50+N

| Size | | | 31 | 41 | 51 | 61 | 71 | 81 | 91 | 101 | 121 | 131 | 151 |
|---|----|--|-------|-------|-------|-------|--------|-------|--------|--------|--------|--------|--------|
| F.L.A. - FULL LOAD CURRENT AT MAX ADMISSIBLE CONDITIONS | | | | | | | | | | | | | |
| F.L.A. - Pump | A | | 1,18 | 1,18 | 1,18 | 3,2 | 3,2 | 3,2 | 3,2 | 1,45 | 1,58 | 1,58 | 1,58 |
| F.L.A. - Total | A | | 9,1 | 9,86 | 12,56 | 15,68 | 18,78 | 19,98 | 20,98 | 23,43 | 26,06 | 28,87 | 33,87 |
| L.R.A. LOCKED ROTOR AMPERES | | | | | | | | | | | | | |
| L.R.A. - Compressor 1 | A | | 33 | 48 | 64 | 74 | 101 | 95 | 111 | 118 | 118 | 140 | 173 |
| F.L.I. FULL LOAD POWER INPUT AT MAX ADMISSIBLE CONDITION | | | | | | | | | | | | | |
| F.L.I. - Pump | kW | | 0,27 | 0,27 | 0,27 | 0,66 | 0,66 | 0,66 | 0,66 | 0,61 | 0,82 | 0,82 | 0,82 |
| F.L.I. - Total | kW | | 4,46 | 4,86 | 6,33 | 7,6 | 9,2 | 10,05 | 11,15 | 12,9 | 14,6 | 15,85 | 18,2 |
| M.I.C. MAXIMUM INRUSH CURRENT | | | | | | | | | | | | | |
| M.I.C. - Value | A | | 35,26 | 49,08 | 65,08 | 78,48 | 105,48 | 99,48 | 115,48 | 120,73 | 121,26 | 143,26 | 176,26 |

power supply 400/3/50 (+ NEUTRAL) +/- 6%

Maximum Phase Unbalance: 2%

The pump is included in the total values calculation for non standard voltage please contact Clivet technical office







The units are compliant with the provisions of European standards CEI EN 60204 and CEI EN 60335.

CONNECTION TO THE MAINS

1. Make sure that the sectioning device at the beginning of the unit's power line is opened, locked and equipped with a signal.
2. Open the general line disconnecting switch (if present)
3. Verify that the net is in conformity with the data shown in the registration plate placed on the electrical board.
4. Check the dimensional drawing for the input of the electrical lines
5. Take away the closing plate placed on the electric board (ONLY IF PRESENT) and drill a hole through it to pass the cables through)
6. Protect the cables, using the fairlead of an adequate size.
7. Using the layout of the electrical diagram, single out the connecting terminals of the electrical supply cables, of the neutral (if foreseen) and the PE protection cable
8. Connect the cables to the relevant terminal boards
9. Before supplying power to the unit, make sure that all the safety devices that were removed during electrical connections are positioned again.

SYSTEM COMPOSITION

The system is composed of the following modules: some are optional that could be not installed. Some are supplied in packages separate from the unit: check the shipping document descriptions.

| | |
|---|---|
|  | <p>USER AMBIENT TERMINAL Permits setting the unit function modes (cooling – heating, ECO) and to display the alarms (ELECTRIC, REFRIGERATOR, WATER). This is standard on certain types of unit.</p> |
|  | <p>REMOTE KEYPAD OPTIONAL The interface terminal enables to control every machine function, to program the different adjustment parameters and possibly to display the unit statuses and alarms. It remotely repeats all functions available on the machine keyboard.</p> |
|  | <p>SERVICE KEYPAD OPTIONAL Useful during the maintenance operations; it is fitted with a cable with automotive rapid connector for the utilisation in proximity to the unit. The functionalities are analogous to the remote keypad ones</p> |
|  | <p>MAIN ADJUSTMENT MODULE It controls unit (inlets, outlets, configuration parameters)</p> |
|  | <p>EXPANSION PLUG-IN MODULE It is connected to the main module by a coupling comb. This may be fitted on the unit depending on the unit type and the accessories that are installed.</p> |
|  | <p>SERIAL CONVERTER TTL/RS485 OPTIONAL The supervision services are available, with standard ModBus protocol. Plugged-in in the main module on the electric board (see lay in the wiring diagram). It is possible to connect up to 127 units with a single supervision system. The connection with a PC must use a RS485/232 converter; the serial line RS232 can be max. 10-m long. CONNECTIONS: make reference to the electrical panel and to the SIGNALS AND DATA LINES paragraph.</p> |

FUNCTIONAL CONNECTIONS

FOR ALL THE CONNECTIONS MAKE REFERENCE TO THE ELECTRICAL PANEL SUPPLIED WITH UNIT

Use voltage-free remote control devices that are suitable to commutate very low loads (12V, 10mA)

Few inputs must be activated by configuration parameters whose access is reserved to authorized assistance centres (in order to avoid unauthorized modifications)

1. remote ON / OFF
2. remote SECOND SET POINT (ECO)
3. Machine OPERATION / SHUTDOWN SIGNAL
4. REMOTE KEYPAD
5. RADIANT PANELS
6. SET POINT COMPENSATION for outside temperature/enthalpy
7. SET POINT COMPENSATION with 4-20 mA signal
8. interface via RS485

1. ON / OFF FROM REMOTE CONTROL

Generally the unit is delivered with bridged terminals; if the control is not used, the bridge should not be removed

2. SECOND SET POINT FROM REMOTE CONTROL (ECO)

Use of a second set point (par 29 cooling, par 30 heating), usually higher in summer and lower in winter (ECO). The commutation can be also performed manually by keypad.


The DOMESTIC HOT WATER option may entail modifications of the input in question: see the relative section.

3. SIGNALIZATION OF MALFUNCTIONING/ UNIT FUNCTIONING

Remote signalisation of the proper function (ex. green light) or signalisation of blocks of the machine (ex. red light). Maximum voltage at the terminal ends is 24v ac and maximum power is 1A (ac1) .

4. REMOTE KEYPAD

| | |
|-------------------------|----------------------|
| Max. Length | 100 metres |
| VOLTAGE | 230/1/50 |
| Signal conductor number | 2 + shield |
| Min. length | 0.34 mm ² |




5. DUAL CONTROLS FOR TEMPERATURE – RADIANT PANELS

It is necessary the expansion plug-in module that must be fitted by the client (r refer to the kit instructions) and enabled by parameter 140 = 1.

With the optional kit, the mixed elements can be controlled: fan coils + radiant panels:


- Radiant panel circulator
- Mixing valve (0-10 volt or ON-OFF)
- Delivery probe (NTC type, 10 Kohm at 25°C)
- External control: COOLING/HEATING LIMIT (avoids dew / overheating).

ATTENTION: to prevent dew in summer or superheating in winter, it is very important to fit an external device and interface it with the unit that in case of signalling will force the recycling valve on the radiant panels



The water set point at the radiant panels can be managed in three ways:

1. the valve is managed to maintain the outlet temperature at par 192 value.
2. calculated automatically in function of the external air temperature; two set are calculated (HEAT. / COOL.) that become actives on the basis of the unit operating mode. This configuration is obtained setting par 190=1



3. the installation maintains the summer set point at a value higher than the critical one, to avoid the dew formation on the floor. The unit can be connected via MODBUS to an external device (for example ELFOCONTROL) that transmits the temperature values and the ambient humidity. This configuration is obtained setting par 191 = 1.

If the unit is at service of an installation only for radiant panels (without mixing valve and fan coil) modify the following pump configuration parameters:


| par | Description | Original value | Correct value |
|-----|-------------|----------------|---------------|
| 183 | MaxTempC | 12 | 8 |
| 184 | MinTempH | 12 | 8 |
| 185 | IstTempC | 4 | 2 |
| 186 | IstTempH | 4 | 2 |

6. SET POINT COMPENSATION WITH 4-20 mA SIGNAL (WATER RESET)

It optimizes the energetic efficiency of the unit by automatically changing the set-point according to an external signal of 4-20 ma type. It requests the **expansion plug-in module** option that must be fitted by the client (refer to the kit instructions) and enabled by parameter 140 = 1. This function must be enabled with parameter 18 (=0 not enabled, =1 only summer, = 2 only winter, = 3 summer and winter)

| par | Description | Meaning | value |
|-----|-------------|--|-------|
| 18 | WaterReset | Water Reset enabling 0=No 1=Cool 2=Heat 3=Always | 0 |
| 22 | MaxCWRC | Summer correction max. value | 8 |
| 23 | SWRMaxC | Corresponding signal of the summer MAX. correction | 20 |
| 24 | SWRMinC | Corresponding signal of the summer MIN. correction | 4 |
| 140 | PlugInEn | Enables PLUG-IN presence . 1=YES / 0=NO | |

SET POINT CURVE IN COOLING




7. SET POINT COMPENSATION ON THE TEMPERATURE OR EXTERNAL ENTHALPY

Optimises unit energy efficiency by automatically adjusting the set-point according to enthalpy or the external temperature. Requires the **external humidity probe** or the **external temperature probe**, which are optional for certain types of units and must be installed by the customer and enabled by parameters 152=1 and 156=1.

| par | Description | Meaning | value |
|-----|-------------|---|-------|
| 9 | CompExt | External temp. comp. enabling 0=No 1=Cool 2=Heat 3=Always | 0 |
| 10 | CextMaxC | Ext. Temp. max. summer correction | 15 |
| 11 | CextMinC | Ext. Temp. min. summer correction | 30 |
| 14 | MaxCExtC | Summer correction max. value | 8 |
| 16 | HExtMinC | Ext. enthalpy min. correction | 10,5 |
| 17 | HExtMaxC | Ext. enthalpy max. correction | 13,5 |
| 152 | TextEn | EXT. Air probe presence 1=YES, 0=NO | |
| 156 | URProbeExt | Enables external UR% probe. 1=YES, 0=NO | |

SET POINT CURVE IN COOLING





8. UNIT INTERFACE VIA RS 485

Below the indications for the serial connection ; refer anyway to the CLIVET “RS 485 NETWORKS – GUIDELINES” document and ask for the COMMUNICATION PROTOCOL about the COMPACT electronics

- The total length of each single serial line, don't have to be over 1000 metres
- The potential difference between the “ground” of two RS485 switches must be less of 7 V
- Couple of conductors twisted and shielded
- Section of conductor $0.22\text{mm}^2 \dots 0,35\text{mm}^2$
- Nominal capacity between conductors $< 50 \text{ pF/m}$ nominal impedance 120Ω
- Recommended cable BELDEN 3105 A

TYPE OF NETWORK

The serial lines must be connected in bus topology, i.e. nodes to more points are not admitted





SHIELD

It must be connected to a ground without disturbances

Connected to ground in only one point

Provide to the shield continuity during all the serial cable extension.



START-UP

ALL THE EQUIPMENT MUST BE COMMISSIONED BY AUTHORISED SERVICE CENTRES.
THIS SERVICE IS LIMITED TO START-UP OF THE UNIT ONLY AND NOT THE CONNECTIONS OR INSTALLATION OF THE SYSTEM.

ONLY QUALIFIED TECHNICIANS MUST PERFORM THE FOLLOWING OPERATIONS.

PRELIMINARY CHECKS

Before checking, please verify the following

1. the unit should be installed properly and in conformity with this manual.
2. the electrical power supply line should be sectioned at the beginning.
3. the sectioning device is locked and the proper warning "not to operate" sign is placed on the handle.
4. make sure no tension is present
5. the coils must be clean and free of obstacles
6. the ventilators must be free of leaves, cardboard, fixed obstacles (beams, barriers, etc.), snow, etc
7. the external ventilators must not be blocked

The external ventilators can be subject to a temporary block, especially if the inactivity period before the first start-up was quite long or if outside temperature is very low. It is also possible to unblock them manually (ONLY WHEN THE UNIT IS UNPLUGGED – RISK OF INJURES) so that jams or electric overloads are avoided when the unit is restarted.

REFRIGERANT SYSTEM

Carefully check the refrigerating circuit: the presence of oil stains can mean leakage caused by transportation, movements or other).

Open the cocks of the refrigerator circuit, if there are any.

Using the unit manometers, if present, or service manometers, verify that the refrigerating circuit is in pressure.

Make sure that all the service outlets are closed with proper caps; if caps are not present a leak of refrigerant can be possible.

WATER SYSTEM

Ensure that the plumbing system has been washed. Drain the wash water before connecting the unit to the system.

Check that the water circuit has been filled and pressurised.

Perform a seal check at max. working pressure checking that no leaks are present.

Check that the shut-off valves in the circuit are in the "OPEN" position.

Check that there is no air in the circuit. If required, bleed it using the vent valves in the system.

Check that there are no ARIES EFFECTS in the transient (pump and / or valve activation/deactivation)

When using antifreeze solutions, make sure the glycol percentage is suitable for the type of use envisaged.

| % weight of ethylene glycol | 10 % | 20 % | 30 % | 40 % |
|-----------------------------|--------|--------|---------|---------|
| Freezing point | - 4 °C | - 9 °C | - 15 °C | - 23 °C |
| Safety temperature | - 2 °C | - 7 °C | - 13 °C | - 21 °C |

Check that the circulator pumps are not blocked. In fact, their motor shaft may seize up, especially after long shutdowns. Unblocking can be accomplished with a screwdriver using the purge hole.

ELECTRICAL SYSTEM

Check the proper tightening of the screws that fix the conductors to the electrical components in the board (during handling and transportation, the vibrations could have loosened them).

Verify that the unit is connected to the ground plant.

Control that all panels and protection devices of the unit are repositioned and blocked.

Charge the unit by closing the sectioning device, but leave it on OFF.

Make sure that the tension and net frequency values are within the limit of:

230 +/- 10% single phase unit; 400/3/50 +/- 10% three-phase unit

Control the unbalancing of the phases: it must be lower than 2% .

Example:

L1 - L2 = 388 V, L2 - L3 = 379 V, L3 - L1 = 377 V

average of the measured values = $(388 + 379 + 377) / 3 = 381$

maximum deviation from the average = $388 - 381 = 7V$

Unbalancing = $(7/381) \times 100 = 1.83\% = \text{ACCEPTABLE}$

Operating out of the indicated limits causes the loss of the guarantee as well as very serious damages.

IF THE CRANKCASE RESISTANCES ARE FITTED

when the unit is started up for the first time and following all prolonged periods of inactivity is OBLIGATORY to connect the oil resistances on the compressor crankcase at least 8 hours before the compressor is to be started.

BEFORE POWERING THE RESISTANCES, OPEN THE COMPRESSORS COCKS, IF PRESENT.

To supply the resistances is necessary to switch off the isolator switch on the unit.

To make sure that the resistances are working, check the power input with amperometric pliers.

At start-up the compressor crankcase temperature on the lower side must be higher at least of 10°C than the outside temperature.

DO NOT START THE COMPRESSOR WITH THE CRANKCASE OIL BELOW OPERATING TEMPERATURE.

VERIFY TENSIONS – ABSORPTIONS

Check that the temperatures of the fluids are included in the WORKING LIMITS.

If the controls of the previous paragraphs are positive, it is possible to restart the unit.

For information on the control panel, refer to the paragraph CONTROL.

While the unit is working (ATTENTION ELECTRIC RISK: WORK SAFELY) check:

- Power supply tension
- Phase unbalance
- Total absorption of the unit
- Absorption of the single electric loads

UNIT EQUIPPED WITH SCROLL COMPRESSORS

The GENERAL TECHNICAL DATA table shows the type of compressor on the unit.

The Scroll compressors have only one direction of rotation.

In the event that the direction is reversed, the compressor will not be damaged, but its noisiness will increase and pumping will be negatively affected. After a few minutes, the compressor will stop because of the activation of the thermal protection. In this event, cut the power and reverse the 2 phases on the machine power.

Prevent the compressor from working with in reverse rotation: more than 2-3 anomalous starts up can damage it.

Make sure the direction of rotation is correct, measure the condensation and suction pressure. Pressure must clearly differ: at the start, the suction pressure decreases whilst the condensation pressure increases.

The phase optional monitor, which controls the phase sequence, can be installed later.

REMOTE INPUT CONFIGURATIONS

Check used remote inputs are activated (ON-OFF etc.) as given in the instructions in the ELECTRIC WIRING chapter.

SETTING THE SET-POINT

Check if it is necessary to modify the set-points shown in the CONTROL chapter

EVAPORATOR WATER FLOW RATE

Check that the difference between the temperature of exchanger return and supply water corresponds to power according to this formula:

$$\text{unit cooling power (kW)} \times 860 = \text{Dt (}^{\circ}\text{C)} \times \text{flow rate (L/h)}.$$

The cooling power is shown in the TABLE ON GENERAL TECHNICAL DATA included in this manual, referred to specific air/water conditions, or in the tables on cooling PERFORMANCE IN THE TECHNICAL BULLETIN referred to various conditions of use.

Check for water side exchanger pressure drops:

- Determine the water flow rate.
- Measure the difference in pressure between exchanger input and output and compare it with the graph on WATER SIDE EXCHANGER PRESSURE DROPS.

The measurement of pressure will be easier if pressure gauges are installed as indicated in the DIAGRAM OF SUGGESTED WATER CONNECTIONS .

REFRIGERANT CIRCUIT PARAMETER CHECK

Detecting the operational conditions is useful to control the unit along time: the performed records must be kept and be available during maintenance interventions.

When the unit works in stable conditions and according to the operating limits, take note of the following data:

1. compressor discharge temperature (WARNING – BURN DANGER)
2. condensing pressure
3. liquid temperature
4. dehydrator filter upstream and downstream temperature
5. return pressure
6. return temperature
7. exchanger input water temperature
8. exchanger output water temperature
9. fresh air temperature (coil input)
10. air temperature coming out from fans

CONTROL

The HEATING mode functions are active only on HEAT PUMP unit version .
 In ONLY COOL units, the relative parameters are VISIBLE but NOT ACTIVE , for example the winter setpoint.

OPERING MODES

| | |
|-------------|---|
| ON – OFF | Unit can be switched on and off by: <ul style="list-style-type: none"> • keypad • remote switch (see ELECTRICAL CONNECTIONS paragraph) • Supervisor |
| COOLING | The compressor is activated with outlet temperature higher than set point |
| | To switch from cooling to heating and vice versa, proceed as follows: Turn the unit OFF Wait until the plant water temperature (and external air) fall within the operating limits. They can be switched over from the remote controls (refer to the ELECTRIC WIRING paragraph). |
| ECO | A secondary set-point can be used, with respect to the comfort setting |
| MAINTENANCE | the plant can be kept within the operating limits even when the unit is OFF or on STANDBY |

CHARACTERISTICS

THERMOREGULATION

The thermoregulation is based on the OUTLET temperature.

The unit is dimensioned for a determined TOTAL HEAD between input and output water temperature.

Usually the project step is 5°C; if the value is different, it is necessary reset parameters 37 and 38 (accessible to the service centre).

In function of the total head, the installation determines the head quote that every resource (compressor, heating elements) is able to provide: the STEP HEAD.


The control logic insert gradually the resources when the outlet temperature is higher than the set point + the head step.

The resources are activated one at a time and only at the SCAN TIME expiring.

The scan time is not fixed but it changes in function of the margin between the water outlet temperature and the Set point value. Higher is the margin value (both in positive and in negative) shorter will be the space among the scan points.

The scan time value is visualized at status 4; when the status 3 has reached the status 4 value, the compressor operating request is activated.


What above described, refer to the COOLING operating; in HEATING the logic is the same but “overtuned” (compressor insertion for outlet temp. < set-point –step head)



SET-POINT COMPENSATIONS

The compensations are evolved functions to protect the compressors and to adapt, as far as possible, the unit operating to the installation and use characteristics.

The compensations prolong the compressor operating time and limit the start number; to do this they delay the compressor insertion point adding an offset.




- The compensation on the DURATION is useful when the installation water content is limited.
- The compensation on the CHARGE is useful if the variable charge is present.

For the enabling and the configuration is necessary the parameter modification with reserved access to the service centres. In industrial applications where is requested a temperature check is possible to disable the COMPENSATIONS.

SET-POINT CORRECTIONS

The correction aim is to optimize the unit energetic efficiency.

To do this the corrections modify the set point in a dynamic way in function of determined variables: for example in summer operating with low external temperatures, so with a reduced charge, is possible to obtain the internal comfort also with set point higher than standard, obtaining an higher energetic efficiency.



The static set point can so be modified in a dynamic way by two CORRECTIONS based on as many unit external factors:

- correction based on the ext. temp. / enthalpy
- correction based on the Water reset (4-20 mA signal provided by the Client)

The correct set point, to whom have been summed or removed the corrections, is named ACTUAL set-point and it is visible at status n°1.

The STATA menu visualizes the compensation value on the ext. temperature (status 5) and WR (status 6)

For further details see the ELECTRICAL CONNECTIONS section.

CIRCULATION PUMP

The pump is always activated with the units ON.

The delivery capacity is variable to soften the thermal shock to the compressors when the plant temperature is close to the threshold limits.

Delivery capacity depends on the intake temperature:

- SUMMER: high water temperature reduces delivery

CIRCULATION PUMP – CONDENSER (RUNNING WATER)

The pump is started BEFORE the compressor start and stopped AFTER the condenser stop.

SET POINT

The control is performed on the OUTLET TEMPERATURE, comparing it with the actual set-point value (visible at status 1).

SET-POINT CALCULATION:

- desired medium outlet water temperature = 7°C
- Project temperature differential = 5°C (that is inlet water = 12°C)
- ¼ of the project temperature differential = $5 / 4 = 1.25^\circ\text{C}$
- set-point to be set = $7 - 1.25 = 5.7^\circ\text{C}$

SECONDARY SET POINT – ECO

A secondary set point can be used with different levels to the “normal” set point.

It is normally set to give lower energy consumption with respect to the comfort setting:

- The SECONDARY SUMMER set point is higher than the SUMMER setting.

It can be set according to individual requirements.

- Secondary summer set-point parameter 29

It can be activated from the keyboard, supervisor unit or the remote control. To change it using the remote control refer to the ELECTRIC WIRING paragraph.

MAINTENANCE

This way, the plant can be kept within the operating limits even when the unit is OFF or on STANDBY, for example during the weekend or the night-time.

Periodically the system activates the circulation pump, measures the water temperature and activates the compressor, if required, to take the water temperature to the set-point level.

- Summer maintenance set-point par 42

This function is activated by parameters 44 (activate summer maintenance level)

DUAL CONTROLS FOR TEMPERATURE – RADIANT PANELS

With the optional kit, a mixed plant can be controlled:

- Fan coil (with the set-points seen above)
- Radiant panels (with specific radiant set-points)

The radiant set point can be determined in different ways, for further details see the ELECTRICAL CONNECTIONS section.

FUNCTIONING WITH ETHYLENE GLYCOL

The units foreseen to function with glycoled water come out from the premise with standard parameters.

After having added glycol ethylene to water, the technician will properly set the plant.


Parameter to modify:

- 32 Summer set point
- 77 Antifreeze heater set
- 80 Antifreeze alarm
- 84 Antifreeze pre-alarm threshold

USER KEYPAD

The keyboard allows visualizing and changing the functioning conditions of the unit.


The service keyboard is needed to visualize or modify the functioning parameters.



ON - OFF

The ON-OFF control from the keyboard allows activating or deactivating the normal functioning of the unit.

SETTING THE OPERATING MODE

COOLING: to set the SUMMER operating mode, press the  key for a few moments. When the mode has been activated, the corresponding green led lights up.

When the mode has been activated, the corresponding green led lights up.

MAINTENANCE: The operating mode leds remain alight even when the machine is in the maintenance status. The maintenance set-points (if activated) control the water temperature when the unit is OFF or on STANDBY. To do this, the circulation pump is periodically activated, which tests the water temperature and activates the compressor if required.

SELECTING OPERATING TEMPERATURE

COMFORT: to select the COMFORT temperature for the current operating mode, press the COMFORT key. The set point is only displayed on the machine.

When this mode is activated, the led to the left of the key lights up and remains alight.

ECO: to select the ECONOMIC temperature for the current operating mode, press the ECO key.

In the winter this reduces the set point and increases it in the summer.

When this mode is activated, the green led to the left of the key flashes slowly.

ALARMS

FLASHING LED: there is an anomaly at the AUTOMATIC reset

FIXED LIGHT LED: there is an anomaly at the MANUAL reset

ALARM RESET: TEST + ON/OFF keys pressed simultaneously for more than 2 seconds.

Alarm type:



ELECTRICAL CIRCUIT ALARM

Inlet probe
Outlet probe
Radiant panel water probe
Coil/flow probe
External probe
Pressure 1 probe
Water reset inlet
External relative humidity probe
Phase monitor
Electric heater output probe

Allarme serial faulty



REFRIGERANT CIRCUIT ALARM

HP
LP
CCMP/VENT
HP1 Pre-Alarm
BP1 Pre-Alarm

Allarme serial faulty



WATER CIRCUIT ALARM


Flow pump
System charged with water
Antifreeze alarm
Antifreeze PREAlarm
Pump alarm
C1 PREAlarm
PRad. Cooling limit alarm
PRad. Water frost alarm
Coil frost alarm
Alarm ?T° incongruous
Electric heater antifreeze alarm
Allarme serial faulty

FUNCTIONING TEST


The "Test" key allows the verification of the proper functioning of the all six signalisation LEDs.

When it is pressed, all leds are ON until the key is released.

REMOTE OR SERVICE KEYPAD (OPTIONALS)




1




unit in OFF.
by keypad
by supervisor

2



switching: long ON -
OFF
pressure

3



OUTLET temperature
visualization

Unità in :


- MANTEINTENANCE or
- In TRANSITION mode (for ex. from heating to cooling or to domestic hot H2O)

ACCESSIBLE PARAMETERS FROM REMOTE OR SERVICE KEYBOARD

| num. Par. | Description | Value | UM |
|-----------|--|-------|-----|
| 29 | Summer secondary Set Point | 10 | °C |
| 32 | Summer Set Point | 5.7 | °C |
| 42 | Summer Set Point Maintenance | 20 | °C |
| 44 | Enables Summer Maintenance | 0 | num |
| 77 | Antifreeze heater set point | 4 | °C |
| 80 | Antifreeze alarm | 4 | °C |
| 84 | Limit of deactivation before reaching the antifreeze steps | 4.5 | °C |
| 163 | Configures remote inputs: 1 = H/C by keypad or supervisor | | |
| 216 | Keypad address on Clivet Bus net: 7 =local; 1=remote | 0 | num |


PARAMETER MODIFICATION

1




Push SET button

2




Select the
parameter

3




Modify the value

4



Select another
parameter

5




SET to esc

VISIBLE STATUS FROM REMOTE KEYBOARD OR SERVICE KEYBOARD


| INDICE | DESCRIPTION | VALUE |
|--------|---|----------------|
| 1 | Current Set Point | °C |
| 2 | Temperature drop in degrees centigrade given by the compressor including compensations, if any | °C |
| 3 | Resource activation timer When this value reaches the value fixed at the next status (TimeScan), the thermal regulator will compare the input temperature with the set point and will activate the resources (compressor and/or heaters) | Seconds |
| 4 | Dynamic TimeScan relating to source activation | Seconds |
| 5 | Value in degrees of the external air compensation | °C |
| 6 | Value in degrees of the water reset signal compensation | °C |
| 7 | summation CompCar + CompOn + CompDuty | °C |
| 9 | Value in degrees of the duty-cycle compensation | °C |
| 10 | Inlet temperature | °C |
| 11 | Outlet temperature | °C |
| 12 | Water temperature of refreshing panel | °C |
| 13 | Coil temperature (if condensing in water becomes condenser antifreeze probe) | Bar |
| 14 | Condensing pressure | 0-100% |
| 15 | Fan/Coil percentage 1 | |
| 18 | Heater output temperature | 4-20 mA |
| 19 | Outdoor temperature | °C |
| 20 | Outdoor Humidity | 0-100% |
| 21 | Machine Clock – (only fed unit hours) | Num |
| 22 | Working hours C1 | Num |
| 23 | Pickups C1 | Num |
| 24 | Radiant panel valve status (Out-2) | ON-OFF |
| 25 | Radiant panel valve status | % |
| 26 | Pump percentage | % |
| 27 | Integration heater status | ON-OFF |
| 28 | Refreshing panel valve (Out-1) | ON-OFF |
| 29 | Radiant set Point | °C |
| 30 | Keypad software | EJ – t |
| 31 | Year of certification of the keyboard SW | 2007 |
| 32 | Month of certification of the keyboard SW | 04 |
| 33 | Day of certification of the keyboard SW | 03 |
| 34 | Base Software | EJ – b |
| 35 | Year of certification of the keyboard SW | 2007 |
| 36 | Month of certification of the keyboard SW | 03 |
| 37 | Day of certification of the keyboard SW | 14 |

STATUS DISPLAY



press STATUS button

2



Select the status

3



STATUS to esc

ALARMS

BEFORE RESETTING THE ALARM, IDENTIFY AND ELIMINATE THE CAUSE OF ITS ACTIVATION.

REPEATED RESETS CAN CAUSE IRREVERSIBLE DAMAGES.

The **ALARMS** show a potentially dangerous situation for machine safety.

Before resetting the alarm, discover and remove the cause: repeated resetting could cause irreversible damage. To avoid this, the unit can only be reset **MANUALLY** from the keyboard (only when the cause for the alarm has been removed).

PRE-ALARMS and **SIGNALS** warn of a risky situation. These could be acceptable only if they happen occasionally or in transitory situations (for example when the plant is being started up).

They are reset **AUTOMATICALLY**, as soon as the cause has been removed, without any input from the keyboard.

The pre-alarms are signalled by the fixed C code (not flashing) and on the right the control temperature.

The **FAULTS** warn of problems with the probes and transducers, and are reset **AUTOMATICALLY** to allow the unit to continue running, perhaps with fewer functions.

In case of doubt, always contact an authorised service centre.


The presence of an alarm is signalled by the **ALARM CODE** flashing and the time at which the alarm/alarms occurred.


The cumulative block relay activates simultaneously to the alarm code visualization.


Certain alarms, in particular **PRE-ALARMS**, do not activate the relays.


The complete list of alarms is provided below; depending on the machine type and its configuration, some of the codes shown may not be used.


| | | | |
|--------------|-----------|--|--------|
| E | 00 | Serial faulty - comunicazione tastiera / scheda base | Auto. |
| E | 1 | Faulty or disconnected water inlet probe | Auto |
| E | 2 | Faulty or disconnected water outlet probe | Auto. |
| E | 3 | Faulty or disconnected radiating panel water probe (radiating panel option) | Auto. |
| E | 4 | Faulty or disconnected coil probe | Auto. |
| E | 5 | Electric heater output probe | Auto. |
| E | 6 | Faulty or disconnected external probe | Auto. |
| E | 7 | Faulty or disconnected pressure transducer | Auto. |
| E | 8 | Plug-in pressure probe | |
| C | 9 | Water Reset inlet in short circuit or out of range | Auto. |
| E | 10 | Faulty or disconnected external RH% probe | Auto. |
| E | 11 | High pressure | MANUAL |
| E | 12 | Low pressure | Auto. |
| E | 13 | Condensing fan and/or compressor thermal switch | MANUAL |
| E | 14 | Electric heater antifreeze alarm | MANUAL |
| E | 17 | Pump flow | Auto. |
| E | 18 | System charged with water | MANUAL |
| E | 19 | Phase monitor | Auto. |
| E | 20 | Antifreeze alarm | MANUAL |
| C | 21 | Antifreeze PREAlarm | Auto. |
| C | 22 | High pressure PreAlarm | Auto. |
| C | 24 | Pump change | Auto. |
| E | 25 | flow alarm C1 | Auto. |
| E | 30 | Coil frost alarm | MANUAL |
| E | 31 | Cooling limit alarm (radiating panel option) | Auto. |
| E | 32 | Water frost alarm (radiating panel option) | Auto. |
| E | 33 | Incongruent DeltaT alarm | MANUAL |
| C | 34 | Low pressure pre-alarm | Auto. |
| C / E | 35 | Inlet water temperature over threshold after cooling / domestic hot water switching and vice versa | Auto |
| C | 36 | Incongruent domestic hot H2O thermostat | Auto |

1  flashing
Alarm code
Alarm unit hours

2  opened alarm log
short pressure
ALARM

3  The most recent alarm is
visualized
Use the arrow keys to
visualize other alarms

4  To esc
Short pressure
ALARM

5  To RESET
LONG pressure
ALARM

ROUTINE MAINTENANCE

BEFORE UNDERTAKING ANY SORT OF MAINTENANCE OR CLEANING, DISCONNECT THE ELECTRICAL POWER SUPPLY TO THE UNIT, AND ENSURE THAT OTHER PEOPLE CANNOT RE-CONNECT IT .

All equipment is subjected to wear out.

The maintenance makes :

1. keeps the unit efficiency
2. the components last longer
3. keeps their efficiency and limits breakdowns

Therefore, it is fundamental to perform periodical checks: a few controls can be performed by the user (AUTONOMOUS MAINTENANCE) and they are mainly cleaning activities; otherwise, controls have to be performed by specialized technicians (INSPECTIONS).

The machine should have a log book used to keep track of the performed controls. This will make fixing up breakdowns easier.

Take note of the date, type of control (autonomous maintenance, inspection or fixing up), description of the control, actions taken and so on.

SERVICES : parts subject to intervention

- STRUCTURE
- FRESH AIR COIL
- ELECTRIC FANS
- WATER EXCHANGER

STRUCTURE

Check the condition of the parts making up the structure. Paint so as to eliminate or reduce oxidation at the points in the unit where this problem may occur. Check that the panelling is fastened correctly. Poor fastening may give rise to malfunctions and abnormal noise and vibration.

FRESH AIR COIL

ATTENTION: contact with the exchanger fins can cause cuts. Wear protective gloves to perform the above described operations.

It is extremely important that the battery gives the maximum thermal exchange; therefore, its surface must be cleaned from dust and deposits. Remove all impurities from the surface.

Using an air pressure gun, clean the aluminum surface of the battery. Be careful to direct the air in the opposite direction of the fan air movement. Hold the gun parallel to the fins to avoid damages. As an alternative, an aspirator can be used to suck impurities from the air input side.

Verify that the aluminum fins are not bent or damaged. In the event of damages, contact the authorized assistance center and get the battery "ironed out" in order to restore the initial condition for an optimal air flow.

ELECTRIC FANS

Make sure that the fans and the relative protection grids are well fixed.

Check, if possible, the unbalances of the electro-fan evident by noise and anomalous vibrations. Verify that the terminal protection covers are closed and the cable holders are properly positioned.

WATER EXCHANGER

It is very important for the exchanger to be able to provide the maximum thermal exchange. Therefore, it is essential for the inner surfaces to be clean of dirt and incrustations.

Periodically check the difference between the temperature of the supply water and the condensation temperature. If the difference is greater than 8°C–10°C it is advisable to clean the exchanger.

MAINTENANCE INSPECTIONS

Foresee inspection assistance carried out by authorized centers or by qualified personnel.

The inspections should be carried out at least:

- Every year for only the cooling units
- Every six months for the cooling and warming units

The frequency, however, depends on the use: in the event of frequent use (continuous or very intermittent use, near the operating limits, etc) or critical use (service necessary) it is recommended to plan inspections at close intervals.

For units equipped with safety valves, follow the Manufacturer's instructions.

Verify periodically the cleaning of the safety valves and that oxidative / corrosive phenomena are not present, in particular for installations near the sea, in industrial areas or in rooms with a corrosive atmosphere.

The inspections to be performed are as follows:

- verify the power supply tension (when emptied or filled)
- inspect the electrical board (status of solenoid starter contacts, terminal closings, the status of wiring and relevant insulations)
- inspect the absorption of the single electrical loads
- verify the cleaning and the efficiency of the exchangers
- inspect the cleaning of the filters (air/water)
- verify the leakage from the refrigerating circuit
- Verify the protection devices (safety valves, pressure switches, thermostats, etc.), the adjustment systems, the control devices (alarm signalizations, probes, manometers, etc)
- check the operating parameters of the refrigerating circuit (see the following REFRIGERANT TABLES and the START-UP section)

97/23 CE PED DIRECTIVE

97/23 CE PED DIRECTIVE gives instructions for installers, users and maintenance technicians as well. Refer to local actuation norms.

In Italy, refer to the Ministerial Decree of 1st December 2004 no. 329 (and following modifications) which defines the performances to be executed; the units of 1st category and those defined by the art. 3.3 97/23/EC are not included in this regulation (see the serial number plate on the unit) .

Briefly and as an example, see the following :

1. **COMPULSORY VERIFICATION OF THE FIRST INSTALLATION** only for units assembled on the installer's building site (for ex. Condensing circuit + direct expansion unit)
2. **CERTIFICATION OF SETTING IN SERVICE** for all the units
3. **PERIODICAL VERIFICATIONS** to be executed with the frequency indicated by the Manufacturer (see the MAINTENANCE INSPECTIONS paragraph)

PUT AT REST

If a long period of inactivity is foreseen, for example the winter for the cooling unit, the following is recommended:

- to turn the power off in order to avoid electrical risks or damages by lightning strike
- to avoid the risk of frosts as shown in the HYDRAULIC CONNECTIONS section, and, in particular
 - to empty or add glycole in the plant sections subjected to temperatures below zero
 - to empty or add glycole in the water heating coils, also in summer
 - to power antifreeze resistances if present

If the period of inactivity is particularly long or in the event of extremely low temperatures, the external fans can be blocked temporarily; therefore, it is recommended to switch them on every month in order to avoid seizures or electrical overloads when the unit will be switched on.

The restarting of the unit has to be carried out by qualified personnel, in particular, after the winter break for cooling units or when seasonal switching should be performed.

When restarting, refer to the SWITCHING ON section.

Schedule technical assistance in advance to avoid hitches and be able to use the installation when necessary.

REFRIGERANT TABLES

THIS SECTION IS DEVOTED ONLY TO QUALIFIED TECHNICIANS THAT KNOW THE FOLLOWING:

- THE OPERATIONAL PRINCIPLES OF THE REFRIGERATING CIRCUIT OPERATION
- THE MODES OF DETECTING TEMPERATURE AND PRESSURE
- THE RISKS RELEVANT TO THESE OPERATIONS

The data of the tables allow the testing of the refrigerating circuit operation by the detection of a few objective parameters. The data are significant if they are detected simultaneously and while the refrigerating circuit is running.

| OVERHEATING = return temperature – Saturation temperature | | SUBCOOLING = condensing temperature (pressure *) – liquid temperature | |
|---|---------------------------|---|-----------------------------|
| Return pressure | 7.2 bar | Condensing pressure | 29.6 bar |
| Return temperature | 7.3 °C | Liquid temp. | 45 °C |
| overheating | 7.3 – 0.8 = 6.5 °C | subcooling | 49.91 – 45 = 4.91 °C |

* It is important that the condensation pressure is detected as close as possible to the point where the liquid temperature is detected, in the event that the calculation will be effected by the losses of charge (and, therefore, of temperature) caused by the refrigerating circuit components placed between the two measurement points.

Pg = P gauge = relevant pressure (read on the pressure gauge) , Ts = saturation pressure

For R410A the glide was not considered, since it is close to 0

| Pg | Ts [°C] | Pg | Ts [°C] | Pg | Ts [°C] | Pg | Ts [°C] | Pg | Ts [°C] | Pg | Ts [°C] | Pg | Ts [°C] | Pg | Ts [°C] | Pg | Ts [°C] |
|-----|---------|------------|-------------|------|---------|------|---------|------|---------|-------------|--------------|------|---------|------|---------|------|---------|
| 0.0 | -51.66 | 5.0 | -8.69 | 10.0 | 10.42 | 15.0 | 23.74 | 20.0 | 34.22 | 25.0 | 42.95 | 30.0 | 50.47 | 35.0 | 57.10 | 40.0 | 63.02 |
| 0.2 | -48.02 | 5.2 | -7.73 | 10.2 | 11.03 | 15.2 | 24.20 | 20.2 | 34.59 | 25.2 | 43.27 | 30.2 | 50.75 | 35.2 | 57.35 | 40.2 | 63.25 |
| 0.4 | -44.83 | 5.4 | -6.79 | 10.4 | 11.63 | 15.4 | 24.66 | 20.4 | 34.97 | 25.4 | 43.59 | 30.4 | 51.03 | 35.4 | 57.60 | 40.4 | 63.47 |
| 0.6 | -41.98 | 5.6 | -5.87 | 10.6 | 12.23 | 15.6 | 25.12 | 20.6 | 35.34 | 25.6 | 43.90 | 30.6 | 51.31 | 35.6 | 57.85 | 40.6 | 63.69 |
| 0.8 | -39.40 | 5.8 | -4.97 | 10.8 | 12.82 | 15.8 | 25.57 | 20.8 | 35.71 | 25.8 | 44.22 | 30.8 | 51.59 | 35.8 | 58.09 | 40.8 | 63.92 |
| 1.0 | -37.03 | 6.0 | -4.10 | 11.0 | 13.40 | 16.0 | 26.01 | 21.0 | 36.08 | 26.0 | 44.53 | 31.0 | 51.86 | 36.0 | 58.34 | 41.0 | 64.14 |
| 1.2 | -34.84 | 6.2 | -3.24 | 11.2 | 13.97 | 16.2 | 26.46 | 21.2 | 36.44 | 26.2 | 44.85 | 31.2 | 52.14 | 36.2 | 58.58 | 41.2 | 64.36 |
| 1.4 | -32.81 | 6.4 | -2.40 | 11.4 | 14.54 | 16.4 | 26.90 | 21.4 | 36.81 | 26.4 | 45.16 | 31.4 | 52.41 | 36.4 | 58.82 | 41.4 | 64.58 |
| 1.6 | -30.90 | 6.6 | -1.57 | 11.6 | 15.10 | 16.6 | 27.33 | 21.6 | 37.17 | 26.6 | 45.47 | 31.6 | 52.68 | 36.6 | 59.07 | 41.6 | 64.79 |
| 1.8 | -29.10 | 6.8 | -0.77 | 11.8 | 15.66 | 16.8 | 27.76 | 21.8 | 37.52 | 26.8 | 45.77 | 31.8 | 52.95 | 36.8 | 59.31 | 41.8 | 65.01 |
| 2.0 | -27.39 | 7.0 | 0.02 | 12.0 | 16.20 | 17.0 | 28.19 | 22.0 | 37.88 | 27.0 | 46.08 | 32.0 | 53.22 | 37.0 | 59.55 | 42.0 | 65.22 |
| 2.2 | -25.78 | 7.2 | 0.80 | 12.2 | 16.74 | 17.2 | 28.62 | 22.2 | 38.23 | 27.2 | 46.38 | 32.2 | 53.49 | 37.2 | 59.78 | 42.2 | 65.44 |
| 2.4 | -24.24 | 7.4 | 1.56 | 12.4 | 17.28 | 17.4 | 29.04 | 22.4 | 38.58 | 27.4 | 46.69 | 32.4 | 53.75 | 37.4 | 60.02 | 42.4 | 65.65 |
| 2.6 | -22.76 | 7.6 | 2.31 | 12.6 | 17.81 | 17.6 | 29.45 | 22.6 | 38.93 | 27.6 | 46.99 | 32.6 | 54.02 | 37.6 | 60.26 | 42.6 | 65.87 |
| 2.8 | -21.35 | 7.8 | 3.05 | 12.8 | 18.33 | 17.8 | 29.87 | 22.8 | 39.28 | 27.8 | 47.28 | 32.8 | 54.28 | 37.8 | 60.50 | 42.8 | 66.08 |
| 3.0 | -20.00 | 8.0 | 3.77 | 13.0 | 18.85 | 18.0 | 30.28 | 23.0 | 39.62 | 28.0 | 47.58 | 33.0 | 54.54 | 38.0 | 60.73 | 43.0 | 66.29 |
| 3.2 | -18.69 | 8.2 | 4.48 | 13.2 | 19.36 | 18.2 | 30.69 | 23.2 | 39.96 | 28.2 | 47.88 | 33.2 | 54.80 | 38.2 | 60.96 | 43.2 | 66.50 |
| 3.4 | -17.44 | 8.4 | 5.18 | 13.4 | 19.87 | 18.4 | 31.09 | 23.4 | 40.30 | 28.4 | 48.17 | 33.4 | 55.06 | 38.4 | 61.20 | 43.4 | 66.71 |
| 3.6 | -16.22 | 8.6 | 5.87 | 13.6 | 20.37 | 18.6 | 31.49 | 23.6 | 40.64 | 28.6 | 48.46 | 33.6 | 55.32 | 38.6 | 61.43 | 43.6 | 66.92 |
| 3.8 | -15.05 | 8.8 | 6.55 | 13.8 | 20.86 | 18.8 | 31.89 | 23.8 | 40.98 | 28.8 | 48.76 | 33.8 | 55.58 | 38.8 | 61.66 | 43.8 | 67.13 |
| 4.0 | -13.91 | 9.0 | 7.22 | 14.0 | 21.36 | 19.0 | 32.28 | 24.0 | 41.31 | 29.0 | 49.05 | 34.0 | 55.84 | 39.0 | 61.89 | | |
| 4.2 | -12.81 | 9.2 | 7.88 | 14.2 | 21.84 | 19.2 | 32.68 | 24.2 | 41.64 | 29.2 | 49.33 | 34.2 | 56.09 | 39.2 | 62.12 | | |
| 4.4 | -11.74 | 9.4 | 8.53 | 14.4 | 22.32 | 19.4 | 33.07 | 24.4 | 41.97 | 29.4 | 49.62 | 34.4 | 56.34 | 39.4 | 62.35 | | |
| 4.6 | -10.69 | 9.6 | 9.16 | 14.6 | 22.80 | 19.6 | 33.45 | 24.6 | 42.30 | 29.6 | 49.91 | 34.6 | 56.60 | 39.6 | 62.57 | | |
| 4.8 | -9.68 | 9.8 | 9.79 | 14.8 | 23.27 | 19.8 | 33.84 | 24.8 | 42.62 | 29.8 | 50.19 | 34.8 | 56.85 | 39.8 | 62.80 | | |

TROUBLESHOOTING

THE OPERATIONS MUST BE CARRIED OUT BY TECHNICAL QUALIFIED PERSONNEL HAVING THE REQUISITES UNDER LAW REQUISITES AND IN CONFORMITY WITH THE SAFETY REGULATIONS IN FORCE.

THE INTERVENTIONS WITHIN THE WARRANTY PERIOD WILL BE CARRIED OUT BY AUTHORIZED SERVICE CENTERS.

**BEFORE RESETTING AN ALARM, IDENTIFY AND ELIMINATE ITS CAUSE.
REPEATED RESETS MAY CAUSE SERIOUS DAMAGES.**

In certain machine configurations, some safeties may be placed in series and lead back to a single input on the electronic module.

Therefore, check on the electrical diagram whether the device to which the alarm corresponds has other devices or safeties connected in series.

Below is a list of the possible causes of alarms.

HIGH PRESSURE (in cooling)

1. high water temperature (see operating limits)
2. high air temperature (see operating limits)
3. coil dirty / clogged
4. fans don't work / low speed
5. Manostat/transducer: loose electric contacts/terminals, wiring cables interrupted
6. Anti-condensation gas in the cooling circuit
7. Too much refrigerant
8. Check the trigger point for the manostat and transducer
9. Check the manostat or transducer pressure control point (deposits of oil, dirt, pin blocked mechanically)

LOW PRESSURE (in cooling)

1. low air temperature (see operating limits)
2. low water temperature (see operating limits)
3. insufficient water flow to the exchanger (high thermal difference between input and output)
4. not CONSTANT flow (for example, if the pumps are turned off, certain areas of the plant are excluded or included, other uses are isolated, etc)
5. Water filter clean / valves open /air bubbles in the plant
6. dirty exchanger
7. Manostat/transducer: loose electric contacts/terminals, wiring cables interrupted
8. refrigerant circuit empty, visible leaks of refrigerant/oil, insufficient charge
9. Blocked dehydrator filter
10. thermostatic device not operating correctly
11. Check the trigger point for the manostat and transducer
12. Check the manostat or transducer pressure control point (deposits of oil, dirt, pin blocked mechanically)

FAULTY PROBE

1. Identify the part on the wiring diagram.
2. Loose electric contacts/terminals, leads broken
3. Check the correct probe ohmic level (using a tester)
4. Change the probe.
5. Check the electronic module configuration (only an authorised service centre can do this)
6. Change the electronic module

FAULTY PRESSURE TRANSDUCER

1. Identify the part on the wiring diagram
2. Loose electric contacts/terminals, leads broken
3. Check the pressure test points are in working order
4. Change the part
5. Check the electronic module configuration (only an authorised service centre can do this)
6. Change the electronic module

COMPRESSOR PROTECTION

1. Identify the part on the wiring diagram
2. Loose electric contacts/terminals, leads broken
3. electrical windings interrupted
4. Vacuum power voltage below the limits
5. power contactors / contacts defective
6. start-up power voltage lower than the limits
7. electrical absorption high / unbalanced
8. High compressor discharge temperature > thermostatic device needs calibrating, insufficient refrigerant charge

FAN PROTECTION

1. Identify the part on the wiring diagram
2. fan mechanically jammed, bearings / drive belt (if present)
3. Loose electric contacts/terminals, leads broken
4. electrical windings of fan interrupted
5. power supply voltage below limits
6. electrical absorption high / unbalanced

PUMP PROTECTION

1. Identify the part on the wiring diagram
2. pump jammed (probable for circulator pump after lengthy seasonal shutdowns)
3. Loose electric contacts/terminals, leads broken
4. electrical windings of fan interrupted
5. power supply voltage below limits
6. electrical absorption high / unbalanced

DECOMMISSIONING OF THE UNIT

DISCONNECTING THE UNIT

The units must be disconnected by authorised personnel, who before proceeding must first read the Residual Risks section in this manual.

Before disconnecting the unit, the following must be recovered, if present:

- the refrigerant (if the circuits cannot be isolated): the refrigerant must be removed using suction devices operating in a closed circuit, so as to ensure that none of the compound is released into the atmosphere.
- the antifreeze in the circuits: when removing this fluid, make sure that it does not leak and that it is not released into the environment. The antifreeze fluid must be stored in special containers.

When recovering the substances present in the unit, all measures must be taken to avoid damaging persons and things and polluting the surrounding area.

Awaiting dismantling and disposal, the unit can also be stored outdoors, as bad weather and rapid changes in temperature will not cause damage to the environment, if electric, cooling and hydraulic circuits of the unit are integral and closed.

DISMANTLING AND DISPOSAL

THE UNIT MUST ALWAYS BE SENT TO AUTHORISED CENTRES FOR DISMANTLING AND DISPOSAL.

When dismantling the unit, the fan, the motor and the coil, if operating, may be recovered by the specialist centres for reuse.



All the materials must be recovered or disposed of in compliance with the corresponding national standards in force.

For further information on the decommissioning of the unit, contact the manufacturer.


TECHNICAL DATA

DIMENSIONS

Size 17-21-25





- (1) COMPRESSOR
- (2) EXTERNAL EXCHANGER
- (3) INTERNAL EXCHANGER
- (4) ELECTRICAL PANEL
- (5) WATER INLET 1" GAS
- (6) WATER OUTLET 1" GAS
- (7) FAN
- (8) PUMP
- (9) WATER SIDE SAFETY VALVE
- (10) POWER INPUT
- (11) EXPANSION VESSEL
- (12) CLEARANCE ACCESS RECOMMENDED
- ("G") BARYCENTRE




| | Size | 17 | 21 | 25 |
|------------------|------|-----|-----|-----|
| M | mm | 331 | 350 | 351 |
| N | mm | 179 | 160 | 159 |
| O | mm | 171 | 179 | 178 |
| P | mm | 165 | 157 | 158 |
| Length | mm | 800 | 800 | 800 |
| Depth | mm | 300 | 300 | 300 |
| Height | mm | 643 | 643 | 643 |
| W1 | kg | 19 | 24 | 24 |
| W2 | kg | 11 | 11 | 11 |
| W3 | kg | 18 | 21 | 21 |
| W4 | kg | 10 | 10 | 10 |
| Operating weight | kg | 58 | 66 | 66 |
| Shipping weight | kg | 60 | 68 | 68 |

The units require minimum clearances for operation and maintenance. The following sketch describes the minimum clearances to be considered. In the event of multiple units, the functional clearances must be doubled.

Size 31





- (1) COMPRESSOR
- (2) EXTERNAL EXCHANGER
- (3) INTERNAL EXCHANGER
- (4) ELECTRICAL PANEL
- (5) WATER OUTLET 1" GAS
- (6) WATER INLET 1" GAS
- (7) FAN
- (8) PUMP
- (9) WATER SIDE SAFETY VALVE
- (10) POWER INPUT
- (11) EXPANSION VESSEL
- (12) CLEARANCE ACCESS RECOMMENDED ("G") BARYCENTRE




| | Size | 31 |
|------------------|------|-----|
| M | mm | 358 |
| N | mm | 152 |
| O | mm | 167 |
| P | mm | 169 |
| Length | mm | 800 |
| Depth | mm | 300 |
| Height | mm | 930 |
| W1 | kg | 28 |
| W2 | kg | 12 |
| W3 | kg | 28 |
| W4 | kg | 12 |
| Operating weight | kg | 80 |
| Shipping weight | kg | 83 |

The units require minimum clearances for operation and maintenance. The following sketch describes the minimum clearances to be considered. In the event of multiple units, the functional clearances must be doubled.

Size 41-51





- (1) COMPRESSOR
- (2) EXTERNAL EXCHANGER
- (3) INTERNAL EXCHANGER
- (4) ELECTRICAL PANEL
- (5) WATER OUTLET 1" GAS
- (6) WATER INLET 1" GAS
- (7) FAN
- (8) PUMP
- (9) WATER SIDE SAFETY VALVE
- (10) POWER INPUT
- (11) EXPANSION VESSEL
- (12) CLEARANCE ACCESS RECOMMENDED ("G") BARYCENTRE




| | Size | 41 | 51 |
|------------------|------|------|------|
| M | mm | 352 | 367 |
| N | mm | 158 | 143 |
| O | mm | 148 | 148 |
| P | mm | 188 | 188 |
| Length | mm | 800 | 800 |
| Depth | mm | 300 | 300 |
| Height | mm | 1244 | 1244 |
| W1 | kg | 31 | 35 |
| W2 | kg | 14 | 14 |
| W3 | kg | 39 | 44 |
| W4 | kg | 18 | 17 |
| Operating weight | kg | 102 | 110 |
| Shipping weight | kg | 105 | 113 |

The units require minimum clearances for operation and maintenance. The following sketch describes the minimum clearances to be considered. In the event of multiple units, the functional clearances must be doubled.

Size 61-71




- (1) COMPRESSOR
- (2) ELECTRICAL PANEL
- (3) INTERNAL EXCHANGER
- (4) EXTERNAL EXCHANGER
- (5) HELICAL FANS
- (6) PUMP
- (7) EXPANSION VESSEL
- (8) WATER OUTLET (STANDARD UNIT)
- (9) WATER INLET (STANDARD UNIT)
- (10) POWER INPUT
- (11) CLEARANCE ACCESS RECOMMENDED
- (12) LIFTING HOLES
- ("G") BARYCENTRE



| | Size | 61 | 71 |
|------------------|------|------|------|
| M | mm | 630 | 633 |
| N | mm | 427 | 424 |
| O | mm | 143 | 143 |
| P | mm | 222 | 222 |
| Length | mm | 1087 | 1087 |
| Depth | mm | 411 | 411 |
| Height | mm | 1175 | 1175 |
| W1 | kg | 43 | 44 |
| W2 | kg | 29 | 29 |
| W3 | kg | 27 | 28 |
| W4 | kg | 19 | 19 |
| Operating weight | kg | 118 | 120 |
| Shipping weight | kg | 122 | 124 |

The units require minimum clearances for operation and maintenance. The following sketch describes the minimum clearances to be considered. In the event of multiple units, the functional clearances must be doubled.

Size 81-91-101-121




| GRANDEZZE | | 81 / 91 | 101 / 121 |
|-----------|-----|---------|-----------|
| A | mm. | 150 | 175 |
| B | mm. | 555 | 500 |

- (1) COMPRESSOR
- (2) ELECTRICAL PANEL
- (3) INTERNAL EXCHANGER
- (4) EXTERNAL EXCHANGER
- (5) HELICAL FANS
- (6) PUMP
- (7) EXPANSION VESSEL
- (8) WATER OUTLET (STANDARD UNIT)
- (9) WATER INLET (STANDARD UNIT)
- (10) POWER INPUT
- (11) CLEARANCE ACCESS RECOMMENDED
- (12) LIFTING HOLES
- ("G") BARYCENTRE


| | Size | 81 | 91 | 101 | 121 |
|------------------|------|------|------|------|------|
| M | mm | 745 | 763 | 755 | 756 |
| N | mm | 598 | 580 | 588 | 587 |
| O | mm | 225 | 216 | 228 | 231 |
| P | mm | 283 | 292 | 280 | 277 |
| Length | mm | 1373 | 1373 | 1373 | 1373 |
| Depth | mm | 555 | 555 | 555 | 555 |
| Height | mm | 1225 | 1225 | 1225 | 1225 |
| W1 | kg | 54 | 56 | 58 | 60 |
| W2 | kg | 41 | 42 | 46 | 46 |
| W3 | kg | 40 | 41 | 48 | 50 |
| W4 | kg | 31 | 31 | 37 | 39 |
| Operating weight | kg | 166 | 170 | 189 | 195 |
| Shipping weight | kg | 171 | 175 | 194 | 200 |

The units require minimum clearances for operation and maintenance. The following sketch describes the minimum clearances to be considered. In the event of multiple units, the functional clearances must be doubled.

Size 131-151



- (1) COMPRESSOR
- (2) ELECTRICAL PANEL
- (3) INTERNAL EXCHANGER
- (4) EXTERNAL EXCHANGER
- (5) HELICAL FANS
- (6) PUMP
- (7) EXPANSION VESSEL
- (8) WATER OUTLET (STANDARD UNIT)
- (9) WATER INLET (STANDARD UNIT)
- (10) POWER INPUT
- (11) CLEARANCE ACCESS RECOMMENDED
- (12) LIFTING HOLES ("G") BARYCENTRE



| | Size | 131 | 151 |
|------------------|------|------|------|
| M | mm | 696 | 699 |
| N | mm | 524 | 521 |
| O | mm | 290 | 290 |
| P | mm | 380 | 380 |
| Length | mm | 1710 | 1710 |
| Depth | mm | 684 | 684 |
| Height | mm | 1477 | 1477 |
| W1 | kg | 91 | 94 |
| W2 | kg | 57 | 57 |
| W3 | kg | 70 | 71 |
| W4 | kg | 43 | 44 |
| Operating weight | kg | 261 | 266 |
| Shipping weight | kg | 268 | 273 |

The units require minimum clearances for operation and maintenance. The following sketch describes the minimum clearances to be considered. In the event of multiple units, the functional clearances must be doubled.

TECHNICAL DATA

| Size | | 17 | 21 | 25 | 31 | 41 | 51 | 61 | 71 | 81 | 91 | 101 | 121 | 131 | 151 | |
|--------------------------------------|----|-------|----------|------|------|------|--------|--------|--------|------------|--------|------------|--------|--------|--------|--------|
| COOLING | | | | | | | | | | | | | | | | |
| Cooling capacity | 1 | kW | 4.32 | 5.28 | 5.79 | 7.62 | 8.86 | 11.2 | 14 | 16.7 | 18.6 | 21.3 | 24.4 | 27.4 | 32.3 | 37.5 |
| Compressor power input | 1 | kW | 1.84 | 2.22 | 2.47 | 3.07 | 2.96 | 4.2 | 4.96 | 6.53 | 6.73 | 7.81 | 9.26 | 10.6 | 11.1 | 13.7 |
| Total power input | 2 | kW | 1.89 | 2.28 | 2.53 | 3.23 | 3.12 | 4.34 | 5.27 | 6.84 | 7.03 | 8.11 | 9.56 | 11 | 11.51 | 14.13 |
| EER | 3 | | 2.29 | 2.32 | 2.29 | 2.36 | 2.84 | 2.58 | 2.66 | 2.44 | 2.65 | 2.62 | 2.55 | 2.49 | 2.81 | 2.65 |
| ESEER | | | 2.56 | 2.62 | 2.54 | 2.65 | 3.34 | 3.03 | 3.07 | 2.82 | 3.08 | 2.97 | 2.96 | 2.85 | 3.19 | 3 |
| COMPRESSOR | | | | | | | | | | | | | | | | |
| Type of compressors | 7 | | ROT | ROT | ROT | ROT | SCROLL | SCROLL | SCROLL | SCROLL | SCROLL | SCROLL | SCROLL | SCROLL | SCROLL | SCROLL |
| No. of Compressors | | Nr | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Compressor RPM | 6 | rpm | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Std Capacity control steps | | Nr | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Refrigerant charge (C1) | 8 | kg | 1,5 | 1,6 | 1,6 | 2,4 | 2,8 | 2,9 | 3,8 | 4,5 | 4,9 | 5,6 | 6,3 | 7,1 | 8,3 | 9,5 |
| Refrigerant circuits | | Nr | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| INTERNAL EXCHANGER | | | | | | | | | | | | | | | | |
| Type of internal exchanger | 9 | | PHE | PHE | PHE | PHE | PHE | PHE | PHE | PHE | PHE | PHE | PHE | PHE | PHE | PHE |
| No. of internal exchangers | | Nr | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| Water flow rate (Internal Exchanger) | 1 | l/s | 0.21 | 0.25 | 0.28 | 0.36 | 0.42 | 0.53 | 0.67 | 0.8 | 0.89 | 1.02 | 1.16 | 1.31 | 1.54 | 1.79 |
| Useful pump discharge head | 1 | kPa | 44 | 37 | 32 | 53 | 51 | 33 | 147.1 | 139.3 | 127 | 116.5 | 129.8 | 155 | 138.6 | 121.1 |
| Water content | | l | 1 | 1 | 1 | 1.2 | 1.4 | 1.4 | 1.1 | 1.5 | 1.5 | 1.8 | 2.1 | 2.4 | 2.7 | 3.1 |
| EXTERNAL SECTION FANS | | | | | | | | | | | | | | | | |
| Type of fans | 10 | | AX | AX | AX | AX | AX | AX | AX | AX | AX | AX | AX | AX | AX | AX |
| Number of fans | | Nr | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Standard air flow | 1 | l/s | 655 | 655 | 655 | 1247 | 1310 | 1310 | 1924 | 1924 | 2191 | 2191 | 2085 | 2554 | 2865 | 2865 |
| Installed unit power | | kW | 0.05 | 0.06 | 0.06 | 0.08 | 0.08 | 0.07 | 0.16 | 0.16 | 0.15 | 0.15 | 0.15 | 0.22 | 0.21 | 0.21 |
| CONNECTIONS | | | | | | | | | | | | | | | | |
| Water fittings | | | 1" GAS | | | | | | | | | 1 1/4" GAS | | | | |
| HYDRAULIC CIRCUIT | | | | | | | | | | | | | | | | |
| Max water side pressure | | kPa | 550 | 550 | 550 | 550 | 550 | 550 | 550 | 550 | 550 | 550 | 550 | 550 | 550 | 550 |
| Safety valve calibration | | kPa | 600 | 600 | 600 | 600 | 600 | 600 | 600 | 600 | 600 | 600 | 600 | 600 | 600 | 600 |
| EXPANSION VESSEL | | | | | | | | | | | | | | | | |
| Expansion vessel capacity | | l | 1 | 1 | 1 | 2 | 2 | 2 | 5 | 5 | 5 | 5 | 5 | 5 | 5 | 5 |
| No. of expansion vessels | | Nr | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| POWER SUPPLY | | | | | | | | | | | | | | | | |
| Standard power supply | | V | 230/1/50 | | | | | | | 400/3/50+N | | | | | | |
| NOISE LEVELS | | | | | | | | | | | | | | | | |
| Sound pressure level (1 m) | | dB(A) | 49 | 49 | 51 | 53 | 53 | 55 | 62 | 62 | 63 | 63 | 63 | 64 | 65 | 66 |

| DIMENSIONS | | | | | | | | | | | | | | | | |
|------------------------------|--|----------------|-----|-----|-----|-----|------|------|------|------|------|------|------|------|------|------|
| Length | | mm | 800 | 800 | 800 | 800 | 800 | 800 | 1087 | 1087 | 1373 | 1373 | 1373 | 1373 | 1710 | 1710 |
| Depth | | mm | 300 | 300 | 300 | 300 | 300 | 300 | 411 | 411 | 555 | 555 | 555 | 555 | 684 | 684 |
| Height | | mm | 643 | 643 | 643 | 930 | 1244 | 1244 | 1175 | 1175 | 1225 | 1225 | 1225 | 1225 | 1477 | 1477 |
| Packing volume | | m ³ | 0.2 | 0.2 | 0.2 | 0.4 | 0.5 | 0.5 | 0.7 | 0.7 | 0.7 | 0.7 | 1.1 | 1.1 | 2.1 | 2.1 |
| STANDARD UNIT WEIGHTS | | | | | | | | | | | | | | | | |
| Shipping weight | | kg | 60 | 68 | 68 | 83 | 105 | 113 | 122 | 124 | 171 | 175 | 194 | 200 | 268 | 273 |
| Operating weight | | kg | 58 | 66 | 66 | 80 | 102 | 110 | 118 | 120 | 166 | 170 | 189 | 195 | 261 | 266 |

Shown datas are referred to units working in perfect installation and exchangers' cleaning conditions.

(1) data referred to the following conditions :

internal exchanger water = 12/7°C

external exchanger air intake 35°C

(2) Total input is obtained from compressor input + fan input

(3) EER calculated as the relationship between cooling capacity and total absorbed power.

(4) ROT = rotary compressor

SCROLL = scroll compressor

(5) Nominal values

(6) PHE = plates

(7) AX = axial-flow fan

OPERATING LIMITS (Cooling)

| Size | | 17 | 21 | 25 | 31 | 41 | 51 | 61 | 71 | 81 | 91 | 101 | 121 | 131 | 151 | |
|-------------------------------|------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--|
| EXTERNAL EXCHANGER | | | | | | | | | | | | | | | | |
| Max air intake temperature | 1 °C | 50 | 49 | 48 | 50 | 49 | 49 | 49 | 47 | 47 | 48 | 47 | 47 | 49 | 47 | |
| Min. air intake temperature | 2 °C | -10 | -10 | -10 | -10 | -10 | -10 | -10 | -10 | -10 | -10 | -10 | -10 | -10 | -10 | |
| INTERNAL EXCHANGER | | | | | | | | | | | | | | | | |
| Max water inlet temperature | 2 °C | 21 | 21 | 22 | 22 | 22 | 22 | 23 | 23 | 23 | 23 | 23 | 23 | 23 | 23 | |
| Min. water outlet temperature | 3 °C | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | |

difference between inlet / outlet water temperature = 5°C

Delta temperature min/max=3/8°C

ATTENTION: IN CASE OF PREDOMINANT WINDS, WINDBREAK BARRIERS ARE NECESSARY.

Data refer to unit operating with fans at max. flow-rate. It follows an energy efficiency increase, but also a sound pressure increase of about 2/3 dB(A).

(1) internal exchanger water = 12/7°C

(2) Data referred to still air

(3) external exchanger air intake 30°C

Maximum exchanger inlet water temperature 32°C during max. 15 minutes, thanks to the variable flow rate device for the circulator (standard).

(size 61-71-81-91-101-121)

(4) Antifreeze (std)

CORRECTION FACTOR FOR ANTIFREEZE SOLUTIONS

| % ethylene glycol by weight | | 5% | 10% | 15% | 20% | 25% | 30% | 35% | 40% |
|--|----|-------|-------|-------|-------|-------|-------|-------|-------|
| Freezing temperature | °C | -2.0 | -3.9 | -6.5 | -8.9 | -11.8 | -15.6 | -19.0 | -23.4 |
| Safety temperature | °C | 3.0 | 1.0 | -1.0 | -4.0 | -6.0 | -10.0 | -14.0 | -19.0 |
| Cooling Capacity Factor | Nr | 0.995 | 0.990 | 0.985 | 0.981 | 0.977 | 0.974 | 0.971 | 0.968 |
| Compressor input Factor | Nr | 0.997 | 0.993 | 0.990 | 0.988 | 0.986 | 0.984 | 0.982 | 0.981 |
| Internal exchanger Glycol solution flow Factor | Nr | 1.003 | 1.010 | 1.020 | 1.033 | 1.050 | 1.072 | 1.095 | 1.124 |
| Pressure drop Factor | Nr | 1.029 | 1.060 | 1.090 | 1.118 | 1.149 | 1.182 | 1.211 | 1.243 |

The correction factors shown refer to water and glycol ethylene mixes used to prevent the formation of frost on the exchangers in the water circuit during inactivity in winter.

FOULING CORRECTION FACTOR

| m ² °C/W | INTERNAL EXCHANGER | |
|-------------------------|--------------------|------|
| | F1 | FK1 |
| 0.44 x 10 ⁻⁴ | 1.00 | 1.00 |
| 0.44 x 10 ⁻⁴ | 1.00 | 1.00 |
| 0.88 x 10 ⁻⁴ | 0.97 | 0.99 |

The cooling performance values provided in the tables are based on the external exchanger having clean plates (fouling factor 1). For different fouling factor values, multiply the performance by the coefficients shown in the table.

F1 = Cooling capacity correction factors

FK1 = Compressor power input correction factor

SOUND LEVELS

| | Sound Power Level (dB) | | | | | | | | Sound pressure | Sound power |
|------------|------------------------|-----|-----|-----|------|------|------|------|----------------|-------------|
| | Octave band (Hz) | | | | | | | | | |
| | 63 | 125 | 250 | 500 | 1000 | 2000 | 4000 | 8000 | dB(A) | dB(A) |
| 17 | 67 | 68 | 62 | 61 | 55 | 50 | 39 | 29 | 49 | 61 |
| 21 | 69 | 68 | 62 | 61 | 57 | 51 | 42 | 36 | 49 | 62 |
| 25 | 72 | 70 | 65 | 63 | 58 | 54 | 47 | 39 | 51 | 64 |
| 31 | 73 | 70 | 67 | 64 | 63 | 57 | 49 | 46 | 53 | 67 |
| 41 | 74 | 71 | 68 | 65 | 64 | 58 | 50 | 46 | 53 | 68 |
| 51 | 75 | 70 | 68 | 67 | 65 | 59 | 52 | 46 | 55 | 69 |
| 61 | 86 | 81 | 80 | 72 | 72 | 65 | 56 | 49 | 62 | 77 |
| 71 | 86 | 81 | 80 | 73 | 72 | 65 | 57 | 49 | 62 | 77 |
| 81 | 86 | 81 | 81 | 76 | 72 | 66 | 57 | 50 | 63 | 78 |
| 91 | 86 | 81 | 81 | 75 | 71 | 66 | 58 | 51 | 63 | 78 |
| 101 | 86 | 84 | 77 | 75 | 73 | 69 | 62 | 56 | 63 | 78 |
| 121 | 87 | 83 | 82 | 77 | 74 | 68 | 62 | 55 | 64 | 80 |
| 131 | 87 | 81 | 86 | 77 | 74 | 69 | 59 | 52 | 65 | 81 |
| 151 | 84 | 81 | 88 | 79 | 72 | 69 | 55 | 48 | 66 | 82 |



Measures according to ISO 3744 regulations, with respect to the EUROVENT 8/1 certification.

The sound pressure is measured at 1 m from the external surface of the unit in open field conditions.

data referred to the following conditions :

Internal exchanger water = 12/7°C; outdoor air temperature 35°C



INTERNAL EXCHANGER PRESSURE DROP



UNIT WITHOUT HYDRONIC ASSEMBLY
 DP = PRESSURE DROP
 Q = WATER FLOW

EXCHANGER PRESSURE DROP LIMIT. WARNING: DON'T USE BELOW THIS LIMIT.

PUMP PERFORMANCE



CURVE OF DISCHARGE HEAD WITH HYDRONIC ASSEMBLY
 THE HEADS ARE INTENDED AS AVAILABLE AT THE UNIT CONNECTIONS

DP [KPA] = USEFUL DISCHARGE HEAD
 Q [L/S] = WATER-FLOW RATE

CLIVET SPA
Feltre (BL) ITALY
Tel. + 39 0439 3131
Fax + 39 0439 313300
info@clivet.it

CLIVET ESPAÑA S.A.
Madrid - SPAIN
Tel. + 34 91 6658280
Fax + 34 91 6657806
info@clivet.es

CLIVET UK LTD
Fareham (Hampshire) U.K.
Tel. + 44 (0) 1489 572238
Fax + 44 (0) 1489 573033
info@clivet-uk.co.uk

CLIVET NEDERLAND B.V.
Amerfoort - Netherlands
Tel. + 31 (0) 33 7503420
Fax + 31 (0) 33 7503424
info@clivet.nl

CLIVET SPA
BUREAU DE LIAISON EN FRANCE
Verrières le Buisson - FRANCE
Tel. + 33 (0)1 69 20 25 75
Fax + 33 (0)1 69 20 60 76
info.fr@clivet.com

CLIVET GmbH
Norderstedt - GERMANY
Tel. +49 (0) 40 32 59 57-0
Fax +49 (0) 40 32 59 57-194
info.de@clivet.com

CLIVET TFAIR SYSTEMS (P) LTD.
Matur - INDIA
Tel. +91 8151 232683/5
Fax +91-8151-232684
info@clivettfa.com

The data contained in this bulletin is not binding and may be changed by the manufacturer without prior notice. All reproduction, even partial, is PROHIBITED.

© COPYRIGHT - CLIVET S.P.A. - FELTRE (BL) - ITALIA