

SPLIT TYPE AIR CONDITIONER

Duct Type

INSTALLATION INSTRUCTION SHEET

(PART NO. 9362590013)

For authorized service personnel only.

- WARNING**
- For the air conditioner to operate satisfactorily, install it as confirmed in this installation manual.
 - Installation work must be performed in accordance with national wiring standards by authorized personnel only.
 - Do not turn on the power until all installation work is complete.

STANDARD PARTS

The following installation parts are furnished. Use them as required.


Name and Shape	Qty	Application
Installation template	1	For positioning the indoor unit
Special nut A (large flange)	4	For suspending the indoor unit from ceiling
Special nut B (small flange)	4	For indoor side pipe joint (large pipe)
Coupler heat insulation (large)	2	For indoor side pipe joint (large pipe)
Coupler heat insulation (small)	1	For indoor side pipe joint (small pipe)
Nylon fastener	1	For fixing the drain hose
Remote controller	1	For installing the remote controller cord clamp
Remote controller cord clamp	10	For installing the remote controller cord clamp
Tapping screw (flush heads)	10	For installing the remote controller cord clamp
Auxiliary pipe assembly	1	For wiring condenser pipe side connection
Drain hose insulation	1	To insulate the drain pipe and drain hose connection
Drain pipe insulation	1	For insulating the drain pipe

INDOOR UNIT ACCESSORIES

Power cap	1	For power supply cord insulation
Auxiliary pipe assembly	1	For wiring condenser pipe side connection (May not be supplied, depending on the model)
Edge cover	1	For wiring condenser pipe side edge protection
Tapping screw	2	For cabinet A and cabinet D (mounting) (1)
Bracket	1	For power supply cord binding
Puffy	1	For sealing
Coupler heat insulation	1	For outdoor side pipe joint
Pipe (drain)	2	For outdoor unit drain piping work (May not be supplied, depending on the model)
Flexible hose	2	For outdoor unit drain piping work
Cap (drain)	2	For outdoor unit drain piping work

SELECTING THE MOUNTING POSITION

- Observe the following points together with the customer as follows:
- INDOOR UNIT**
- Install the indoor unit on a clear heading a sufficient strength so that it withstands against the weight of the indoor unit.
 - The fixed rail (center guide) should not be obstructed for air should be able to blow all over the room.
 - Leave the space required to service the air conditioner (Fig. 1).



INDOOR UNIT

- Install the unit where the drain pipe can be easily installed.
- Providing as much space as possible between the indoor unit and the ceiling will make work much easier.

CONNECTION PIPE REQUIREMENT

Diameter	Minimum length	Maximum length	Maximum height between indoor and outdoor unit
Small pipe	1.5	30	30
Large pipe	1.5	30	30

- Use 0.7 mm to 1.2 mm thick pipes.
- Use pipe with water resistant heat insulation.

ELECTRICAL REQUIREMENT

- Electric wire size and fuse capacity.

Power supply cord	MAX	MIN
Power supply cord	3.5	2.5
Condenser pipe	MAX	2.5
Communication	MAX	2.5
Drain pipe	MAX	1.0
Flex cable (A)	1.0	


- Install all electrical works in accordance to local regulation.
- Use REXNOL or equivalent at the connection cord. (Storage area only)
- Install the disconnect device with a contact gap of at least 3 mm meets the units. (Both indoor unit and outdoor unit)

INSTALLATION PROCEDURE

(Install the air conditioner as follows)


1. PIPING CONNECTION DIRECTION AND PREPARATION

- Select piping directions (Fig. 3)




2. DRILLING HOLES FOR BOLTS AND INSTALLING THE BOLTS

- Using the installation template, drill holes for both (four holes).



3. INSTALLING THE HANGERS

- Install the hangers to the ceiling and install special nuts A and B.




4. LEVELING

- Check horizontal direction leveling on top of the unit.




5. SERVICE HOLE DIMENSIONS

- Obtain a service hole with the dimensions shown below.




6. CHECKING THE PIPE CONNECTIONS FOR GAS LEAKING

- For both the indoor and outdoor unit sides, check the joints for one leaking by the use of a gas leakage detector without oil when the pipes are connected.



7. HEAT INSULATION ON THE PIPE JOINTS (INDOOR SIDE ONLY)

- Stick coupler heat insulation (large and small) to the place where condensing pipes.
- When using auxiliary piping with large pipe, stick coupler heat insulation (large) to the pipe at the two places shown below.




8. CHECKING THE PIPE CONNECTIONS FOR GAS LEAKING

- For both the indoor and outdoor unit sides, check the joints for one leaking by the use of a gas leakage detector without oil when the pipes are connected.




9. HEAT INSULATION ON THE PIPE JOINTS (OUTDOOR SIDE ONLY)

- Stick coupler heat insulation (large and small) to the place where condensing pipes.
- When using auxiliary piping with large pipe, stick coupler heat insulation (large) to the pipe at the two places shown below.



10. CHECKING THE PIPE CONNECTIONS FOR GAS LEAKING


- For both the indoor and outdoor unit sides, check the joints for one leaking by the use of a gas leakage detector without oil when the pipes are connected.



11. CONNECTING THE PIPING

1. FLARE PROCESSING

- Cut the connection pipe with pipe cutters so that the pipe is not deformed.
- Hold the pipe downward so that cuttings cannot enter the pipe.
- Remove the flare nut from the indoor unit pipe and outdoor unit and assemble as shown in Table 3 and insert the flare nut into the pipe, and flare with flaring tool.
- Check if the flare part "C" (Fig. 13) is spread uniformly and that there are no cracks.




2. BENDING PIPES

- The pipes are shaped by your hands. Be careful not to collapse them.




3. CONNECTION PIPES

- Detach the caps and plugs from the pipes.
- Center the pipe against part on the indoor unit, turn the flare nut with your hand.



4. HOLD THE TRENCH BRACKET AT THE PIPE

- Hold the trench bracket at the pipe, keeping it to the right angle with the pipe as shown in Fig. 21, in order to tighten the flare nut correctly.




5. TIGHTENING TORQUE

Pipe	Tightening torque
Small pipe	310 to 355 kgf-cm (28.6 to 32.3 N-m)
Large pipe	880 to 1,000 kgf-cm (79.6 to 90.0 N-m)

CAUTION

- Be sure to connect the large pipe after connecting the small pipe completely.



2. ADDITIONAL CHARGE

Refrigerant capacity for a piping length of 5 m (SD45 TYPE), 20 m (SD TYPE) is charged in the outdoor unit at the factory.

When the piping is longer than 5 m (SD45 TYPE), 20 m (SD TYPE) additional charging is necessary.

For the additional amount, see the table below.


Refrigerant	Pipe length	5m	10m	20m	30m	40m	50m	60m
SD45 TYPE	Normal	175	325	475	625	775	925	1075
	Control panel	175	325	475	625	775	925	1075
SD TYPE	Normal	200	400	600	800	1000	1200	1400
	Control panel	200	400	600	800	1000	1200	1400

3. CHECKING THE REFRIGERANT

- When checking the refrigerant, always use a measuring cylinder.
- Add refrigerant from the charging valve after the completion of the work.


4. INSTALLING DRAIN HOSE

- Install the drain hose so that there is a trap. The position of the installed drain hose should have a downward gradient of 1/100 to 1/200.
- Make sure that the drain hose is drained without clogging.
- Use general heat insulating polyethylene pipe (PE) (standard diameter 28 mm) and connect it with adhesive (polyurethane) so that there is no leakage.
- When the hole is being installed, avoid:
 - Causing a fire.
 - Causing an accident.
 - Always heat-insulate the indoor side of the drain hose.
 - Causing air leakage.



5. VACUUM

- Vacuum inside the indoor unit and the piping to a pressure of 1.33 mmHg (0.0133 atm) or less from the desiccant bottle with vacuum pump.
- After vacuuming, check the indoor unit and the piping, remove the cap of the low valve.
- Open the service valve of the low valve from the closed state, (Table 6)
- Tighten the cap of the low valve to the specified torque.



6. ELECTRICAL WIRING

A. For solid core wiring (or F-cable)

- Cut the wire and sets it with cutter or wire-cutting pliers, then strip the insulation to about 15 to 20 mm (25 mm) of exposed the solid core.
- Using a screwdriver, remove the terminal screw on the terminal board.
- Shape the loop wire properly, place it on the terminal board and tighten securely with the terminal screw using a screwdriver.

B. For stranded wiring


- Cut the wire and sets it with a wire cutter or wire-cutting pliers, then strip the insulation to about 15 to 20 mm (25 mm) of exposed the strand wiring.
- Using a screwdriver, remove the terminal screw on the terminal board.
- Using a strand terminal fastener or pliers, securely clamp a round terminal to each stripped wire end.
- Position the round terminal wire, and tighten and tighten the terminal screw with a screwdriver.



C. For stranded wiring

- Cut the wire and sets it with a wire cutter or wire-cutting pliers, then strip the insulation to about 15 to 20 mm (25 mm) of exposed the strand wiring.
- Using a screwdriver, remove the terminal screw on the terminal board.
- Using a strand terminal fastener or pliers, securely clamp a round terminal to each stripped wire end.
- Position the round terminal wire, and tighten and tighten the terminal screw with a screwdriver.






1. INDOOR UNIT SIDE


- Attaching and removing the control box cover.

Fig. 28



- Connection cord and remote controller cord connections.
 - Clamp the connection cord with the cord clamp and the remote controller cord with the nylon clamp. (Fig. 29)

Fig. 29



2. OUTDOOR UNIT SIDE

- Remove outdoor unit cabinet A and connect the power supply cord and the outdoor unit connection cord wired at the indoor unit.
- Fasten the power supply cord and connection cord with cable clips and binders as shown in (Fig. 31).

Fig. 30




Fig. 31




Fig. 32





Fig. 33



7

POWER

WARNING

- The rated voltage of this product is 3ø 4W 380-415V 50Hz.
- Before turning on verify that the voltage is within the 342 to 457V range.
- Always use a special branch circuit and install a special receptacle to supply power to the air conditioner.
- Use a special branch circuit breaker and receptacle matched to the capacity of the air conditioner. (Install in accordance with standard.)
- The special branch circuit breaker is installed in the permanent wiring. Always use a circuit that can trip all the poles of the wiring and has an isolation distance of at least 3mm between the contacts of each pole.
- Perform wiring work in accordance with standards so that the air conditioner can be operated safely and positively.
- Install a leakage special branch circuit breaker in accordance with the related laws and regulations and electric company standards.

CAUTION


- When the voltage is low and the air conditioner is difficult to start, contact the power company the voltage raised.

8

REMOTE CONTROLLER INSTALLATION

- Insert the end of a flat blade screwdriver at the arrow parts of the groove at the side of the remote controller case and remove the remote controller case top by turning the screwdriver.
- Disconnect the remote controller cord from the remote controller terminal board.

Fig. 34



- When remote controller exposed
 - Make a notch in the thin part (part of Fig. 34) at the remote controller case top and bottom with nippers, file, etc.
 - Connect the remote controller cord to the remote controller terminal board specified in (Fig. 35)
 - Clamp the remote controller cord sheath with the binder (small) as shown in Fig. 35.
 - Cut off the excess binder.
 - Clamp the remote controller cord to a wall, etc. with the remote controller cord clamp furnished. (Fig. 36)

Fig. 35






Fig. 36



- When remote controller cord embedded
 - Embed the remote controller cord and box.
 - Pass the remote controller cord through the hole at the remote controller case bottom and install the cord to the box. (Fig. 37)
 - Connect the remote controller cord to the remote controller terminal board specified in (Fig. 35).

Fig. 37 [Example]



- After wiring work is complete, return the remote controller case top to its original state.

CAUTION


- Do not bundle the remote controller cord, or wire the remote controller cord in parallel, with the indoor unit connection wire (to the outdoor unit) and the power supply cord. It may cause erroneous operation.
- When installing the remote controller and cord near a source of electromagnetic waves, separate the remote controller from the source of the electromagnetic waves and use shielded cord.
- Do not touch the remote controller PC board and PC board parts directly with your hands.

9

TEST RUNNING

- REMOTE CONTROLLER
 - Supply power to the crankcase heater 12 hours before the start of operation in the winter.
 - For test running, when the remote controller FAN CONTROL button and MASTER CONTROL button are pressed simultaneously for more than three seconds when the air conditioner is not running, the air conditioner starts and TEST is displayed on the remote controller display. However, the SET TEMP. setting button does not function, but all other buttons, displays, and protection functions operate. (Fig. 38)

Fig. 38



- When EE: EE blinks at the current time display, there is an error inside the air conditioner. If the ZONE CONTROL button and ENERGY SAVE button are pressed simultaneously for more than three seconds, the self diagnosis check will start and the error contents will be displayed at the current time display. (Fig. 39) When the operation lamp lights, press the START/STOP button and after operation lamp goes off, perform the same operation. (Fig. 39) Process the error contents by referring to (Table 8).

Fig. 39




Table 8

Error cord	Error contents
E0:00	Communication error (indoor unit ↔ remote controller)
E1:00	Communication error (indoor unit ↔ outdoor unit)
E2:00	Room temperature sensor open
E3:00	Room temperature sensor shorted
E4:00	Indoor heat exchanger temperature sensor open
E5:00	Indoor heat exchanger temperature sensor shorted
E6:00	Outdoor heat exchanger temperature sensor open
E7:00	Outdoor heat exchanger temperature sensor shorted
EA:00	Outdoor temperature sensor open
Eb:00	Outdoor temperature sensor shorted
EC:00	Discharge pipe temperature sensor open
Ed:00	Discharge pipe temperature sensor shorted
EF:00	Discharge pipe temperature abnormal

- To stop test running, press the START/STOP button.
- For the operation method, refer to the operating manual and perform operation check.
- Check that there are no abnormal sounds or vibration sounds during test running.

2. OUTDOOR UNIT

- When the outdoor temperature drops, the outdoor unit's fans may switch to low speed, or one of the fans may stop intermittently.

ERROR

The LED lamps operate as follows (Table 9) according to the error contents. The LED lamps are on the outdoor unit board.

Table 9


Error display	Error contents
ON OFF	Lighting continued Discharge pipe temperature abnormal
ON 0.5 sec OFF 5 sec	Single quick flashes repeated Outdoor heat exchanger temperature sensor abnormal
ON 0.5 sec OFF 5 sec	Two quick flashes repeated Outdoor temperature sensor abnormal
ON 0.5 sec OFF 5 sec	Three quick flashes repeated Discharge pipe temperature sensor abnormal
ON OFF	Lighting continued High pressure abnormal

When the fault is cleared, the LED lamp goes off. However, for discharge pipe temperature abnormal and high pressure abnormal, the LED lamp lights continuously for 24 hours, as long as the power is not turned off.


10

STATIC PRESSURE CHARACTERISTIC


Fig. 40 FAN PERFORMANCE AND AIR FLOW EXTERNAL STATIC PRESSURE



45 TYPE




36 TYPE




11

APPEARANCE OF OUTDOOR UNIT


Fig. 41



60 TYPE




36/45 TYPE




12

CONNECTION FLANGE DIMENSIONS (INTAKE AND OUTLET)

Fig. 42




Rectangular flange dimensions



OPTIONAL PARTS

When connecting the square duct and round duct, use the optional square flange or round flange and flexible duct.

Fig. 43



Outlet chamber

Model name: UTD-BC200 (P/N 9085835002)

CAUTION

- Tighten the indoor unit connection cord (to the outdoor unit) and power supply indoor and outdoor unit terminal board connections firmly with the terminal board screws. Faulty connection may cause a fire.
- If the indoor unit connection cord (to the outdoor unit) and power supply are wired incorrectly, the air conditioner may be damaged.
- Wire the indoor unit connection cord (to the outdoor unit) by matching the numbers of the outdoor and indoor units terminal board numbers as shown in (Fig. 29).
- Ground both the indoor and outdoor units by attaching a ground wire.
- Unit shall be grounded in compliance with the applicable local and national codes.