

# Краткое руководство по эксплуатации/Skrócona instrukcja obsługi




ecoVIT

	Теплая вода Ciepła woda
	Экономичная установка Ustawienie ekonomiczne
	Горячая вода Gorąca woda

	Летний режим (только теплая вода) Ustawienie na lato (tylko ciepła woda)
	Переходное время Okres przejściowy (wiosna/jesień)
	Сильный холод Ustawienie na zimę (mroźna zima)

Указание: При подключении регулятора зависящего от погодных условий или регулятора температуры в помещении: Установка: "Сильный холод"  
 Uwaga: Przy zastosowaniu regulatora pokojowego lub pogodowego, termostat należy ustawić na zimę (na maksimum).



**F...**  
 Устранение неисправностей  
 Kasowanie awaryjnego wyłączenia

Вкл / Zet / 1  
 0  
 Выкл / Wyt

**5...**  
 Индикация состояния  
 Wyświetlanie funkcji

# Kratke upute za uporabo/Skrócona instrukcija obsluzi



ecoVIT

	Topla voda Topa voda
	Položaj uštede energije Varčevanje energije
	Vrića voda Vroća vode

	Ljetni režim rada (samo topla voda)
	Letni režim (samo topla voda)
	Prijelazni period Prehodno obdobje
	Jaka zima Mrzla zima

**Napomena:** Ukoliko je priključena automatika ili sobni termostat: izabrati položaj „jaka zima“.

**Opomba:** Če je naprava priključena na vremensko vodeno regulaciju, nastavite gumb na položaj „Mrzla zima“.

**Top Panel:** Shows the top of the boiler with a callout to the top panel controls.

**Control Panel:** Detailed view of the control panel featuring two large rotary dials, a digital display showing '88.8', and various function buttons.

**Information Display:** A callout showing a hand pressing an 'i' button next to a display showing '5...'. Labels: **Prikaz statusa** (Status display).

**Reset Function:** A callout showing a hand pressing a button with a flame icon. Labels: **Resetiranje** / **Reset**.

**On/Off Switch:** A callout showing a hand sliding a switch between '1' and '0' positions. Labels: **Uklj / Vkljop** (On/Off) and **Isklj / izkljop** (Off).