Библиотека СОК

WESTEN

The smart choice for your home comfort



quasar D

SPARE PARTS CATALOGUE

- August 2009 -

HOW TO READ THE SPARE PARTS CATALOGUE

In the spare part catalogue, after the exploded diagrams, there are the components lists of the boilers; this is the meaning of the different columns:

Pos.	Identification number of the component in the exploded diagram of the boiler.
Description	Short description of the component.
Code	BAXI S.p.A. code of the component.
Tab. XX	XX is the exploded diagram number of the boiler taken into consideration.
From serial number	Date (year and week) identifying the beginning of production of a component (taken from the serial number of the boiler). e.g. B005: year 2000 (B identifies the decade 2000-2009; 0 identifies the year) – 5th week. If the box is empty, the component is in use from the beginning of production of the boiler.
To serial number	Date (year and week) identifying the end of production of a component (taken from the serial number of the boiler). e.g. B012: year 2000 (B identifies the decade 2000-2009; 0 identifies the year) – 12th week. If the box is empty, the component is still in use.
Interchangeable	It identifies the interchangeability between the new component and the old one. YES: components are interchangeable. NO: components are not interchangeable.

BOILERS CONNECTION BOARD - EXPLODED VIEW
TABELLA COLLEGAMENTO CODICE CALDAIA - ESPLOSO
TABLERO UNIÓN CALDERA - EXPLOSIONADO
TABLEAU CONNECTION CODEX CHAUDIERE - VUE ECLATEE

BOILER CODE CODICE CALDAIA CODIGO CALDERA CODE CHAUDIÈRE	BOILER DESCRIPTION DESCRIZIONE CALDAIA DESCRIPCION CALDERA DESCRIPTION CHAUDIÈRE	EXPLODED REF. RIF. ESPLOSO REF. EXPLOSIONADO RÉF. EXPLOSÉE
BYH442243970	QUASAR D 24	Tab 378
BYH446243970	QUASAR D 24F	Tab 377

quasar D

Pos	Code	Description code	BYH44243970 24	BYH44624397024 F									To serial number	From serial number	Interchangeable:
2	5698660	LEFT PANEL ASSEMBLY ECO4 ATM.	•												
2	5698680	LEFT PANEL ASSEMBLY ECO4 FF		•											
3	5698650	RIGHT PANEL ASSEMBLY ECO4 ATM.	•												
3	5698670	RIGHT PANEL ASSEMBLY ECO4 FF		•											
4	628830	FRONTAL PANEL ASS. ECO4 ATM	•												
4	5117900	FRONTAL PANEL ECO4 WESTEN		•											
5	5117420	TRAVERSE SIDES CONNECTION FF		•											
5	5117460	TRAVERSE SIDES CONNECTION-ATM-	•												
8	5408080	PRESSURE SWITCH PIPE L=270		•											
9	5115860	RESTRICTOR AIR INTAKE D60/43		•											
12	5108690	PLATE BLANKING		•											
13	5407400	SUCTION CAP GASKET		•											
17	5214290	BEND FLUE EMISSIONS ECO4		•											
18	5413850	PRESS.SENS.VENTURI SINGLE TAP		•											
21	5402050	WASHER-SEALING	•	•											
22	5682150	FAN		•											
23	628720	FLUE PRESSURE SWITCH 0,68mbar		•											
24	5407930	PIPE - VALVE COMPENSATION		•											
25	5118150	CONVEYOR ASSEMBLY ECO4 225mm		•											
27	5668290	COMBUSTION CHAMBER ASSEMBLY	•												
27	5700480	COMBUSTION CHAMBER ASSY 225mm		•											
28	5213210	INSULATING PANEL		•											
28	5213220	INSULATING PANEL	•												
29	5213280	INSULATING PANEL	•												
29	5214630	INSULATING REAR PANEL FF 225		•											
30	5213380	FRONTAL INSULATING PANEL	•												
30	5214680	INSULATING FRONTAL PANEL FF225		•											
31	5114290	COMB. CHAMBER FRONTAL PANEL	•												
31	5700540	COMB.CHAMB.FRONTAL PANEL FF225		•											
32	616170	BI-THERMAL HEAT EXCHANGER+ OR	•												
32	5700520	HEAT EXCH.H2O/GAS 225mm VALMEX		•											
33	5403130	O-RING 22 x 3	•	•											
34	5113650	PRIMARY EXCHANGER FIXING CLIP	•	•											
35	5693900	RECT.EXPANSION VESSEL 6l-CIMM-	•												
35	5695230	CIRC.EXPANS.VESSEL 6l ZILMET		•											
36	5698830	PIPE EXPANSION VESSEL	•	•											
37	5663830	SEALED CHAMBER FRONT PANEL		•											
38	5401610	VIEWING WINDOW GASKET		•											
39	5203930	VIEWING WINDOW		•											
40	5115590	SURROUND-SIGHT GLASS		•											
41	5663710	BURNER ASSEMBLY (13 ELEM.)	•												
41	5700530	BURNER ASSEMBLY 11 ELEMENTS		•											


quasar D

Pos	Code	Description code	BYH4424397024	BYH4624397024 F	To serial number	From serial number	Interchangeable:
43	**5698690**	GAS RAMP 13HOLES/INJECT. d1,18	•				
43	**5700500**	GAS RAMP 11 HOLES/INJECT d.1,35		•			
44	**5210790**	INJECTOR (1x0,85) LPG		•			
44	**5214470**	INJECTOR diameter 1,35 mm		•			
44	**5666390**	L.P.G. INJECTORS KIT	•				
44	**5669460**	NATURAL GAS INJECTORS KIT	•				
45	**5407940**	GASKET-BURNER MANIFOLD	•	•			
46	**5657180**	ADAPTOR-MANIFOLD	•	•			
47	**5407810**	GASKET-MANIFOLD ADAPTOR		•			
49	**5409520**	HOSE ADAPTER CAP		•			
59	**8612400**	IGNITION CABLE L=250 ECO4	•	•			
61	**5407830**	INSULATION BOOT - ELECTRODE	•	•			
62	**5409570**	SEALED CHAMBER HOSE ADAPTER		•			
63	**8422570**	ELECTRODE - IGNITION	•	•			
70	**5700340**	ASS.PIPE PUMP/EXCHANGER	•				
70	**5700550**	PIPE ASS.PUMP/EXCH.MAIN4 FF225		•			
72	**5698260**	PUMP ONE SPEED 5meters WILO	•	•			
73	**710139500**	AUTOMATIC AIR VENT	•	•			
75	**5404670**	GROMMET - PIPE ASSEMBLY		•			
80	**5214590**	HYDRAULIC INLET GROUP/PUMP	•	•			
90	**5700370**	CONNECTION CH OUTLET/FILLING	•	•			
91	**5652030**	DRAINING TAP	•	•			
92	**710071200**	SAFETY VALVE 3 bar NOVASFER	•	•			
98	**5214610**	BY-PASS PIPE MAIN 4	•	•			
99	**8380850**	FIXING CLIP	•	•			
100	**5406630**	O-RING	•	•			
102	**5214600**	GROUP HEATING INLET MAIN 4	•	•			
131	**8435400**	NTC SENSOR	•				
131	**8435510**	NTC SENSOR d.14		•			
132	**5402830**	WASHER - SENSOR SEALING	•				
135	**9950760**	THERMOSTAT - LIMIT	•	•			
137	**5214270**	GAS V. ELBOW OUTLET OPEN FLUE	•				
137	**5214280**	GAS VALVE ELBOW OUTLET FF		•			
138	**5402010**	O RING 22.22x2.62	•	•			
139	**5206620**	CONNECTOR-GAS VALVE INLET	•	•			
140	**5653610**	GAS VALVE - SIGMA 845048	•	•			
140	**5665220**	GAS VALVE HON.	•	•			
147	**5693850**	CONNECTION TRAVERSE ECO4	•	•			
151	**5413650**	CONTROL PANEL COVER ECO4	•	•			
152	**5698980**	PRINT.CONTR.PANEL ECO4 WESTEN	•	•			
154	**5702470**	PCB GROUP HONEYWELL SM11460	•	•			
166	**5688430**	TERM.BOARD/DOUBLE FUSE HOLDER	•	•			


quasar D

Pos	Code	Description code	BYH4424397024	BYH4624397024 F									To serial number	From serial number	Interchangeable:
169	8922460	MANOMETER d.40 XGR. BITRON	•	•											
174	628840	KEYBOARD 3 AND 4 BUTTONS	•	•											
182	5701380	WATER INPUT PIPE MAIN 4	•												
182	5701390	WATER INPUT PIPE MAIN 4 FF 225		•											
191	5408970	WASHER - SEALING G1/2	•	•											
231	5409480	FLUE INTAKE		•											
241	5668420	CONVEYOR ASSEMBLY	•												
242	616160	FLUE SAFETY THERMOSTAT 70ø	•												
259	5700470	BRAND QUASAR D WESTEN	•	•											
305	5118160	FAN BRACKET 225		•											
310	5667220	FLOW SWITCH BITRON	•	•											
340	9951690	PRESSURE SWITCH	•	•											
421	5408270	O-RING 11,91 X 2,62 NBR	•	•											
425	5412270	GASKET FAN HT		•											
449	5640030	RETAINING VALVE	•	•											
472	5214580	DHW INLET PIPE MAIN4 OPEN FLUE	•												
472	5214670	DHW INLET PIPE MAIN 4 FF 225		•											
511	5404600	O.R. 17,86x2,62	•	•											
528	8435500	NTC SENSOR D18-ITS2410201/0-		•											
600	5118110	FLAT SPRING diameter 10	•	•											
683	5408810	GASKET(GAS RAMP/SEALED CHAMBER		•											
684	5214650	PIPE EXCH./HEAT.OUTLET FF 225		•											
684	5700350	PIPE EXCHANGER/HEATING OUTLET	•												
686	5663020	BY-PASS PLUG ASSEMBLY	•	•											
692	5114360	PRIMARY EXCHANGER CLIPS	•												
693	5117440	PRINTED CNTR. PANEL PROTECTION	•												
764	5117870	CLIP d.18 BITRON	•	•											
765	710069700	O-RING 9,19X2,62 EPDM	•	•											
999	8414540	CABLE ROOM TH	•	•											
999	8414620	POWER CABLE	•	•											
999	8419040	CABLE - EARTH	•	•											
999	8513660	FAN WIRING ECO4		•											
999	8514030	HIGH VOLTAGE WIRING MAIN 4 SIT	•	•											
999	8514040	HIGH VOLT.WIRING MAIN4 HONEYW.	•	•											
999	8514050	LOW VOLT.WIRING 12P MAIN 4 ATM	•												
999	8514060	LOW VOLT.WIRING 6P.MAIN 4 ATM.	•												
999	8514070	LOW V.WIRING 12P. MAIN4 FF 225		•											
999	8514080	LOW VOLT.WIRING 6P.MAIN4 FF225		•											

Tab 377


12
9
35
12
13
13
17
231
18
425
49
22
25
305
23
8
5
46
3
45
28
29
47
62
27
24
28
32
135
131
34
99
75
511
99
34
75
511
41
43
44
63
61
59
2
30
31
37
38
39
40
259
4
21
36
70
73
72
33
600
765
683
683
511
511
99
98
182
472
421
99
421
686
80
92
764
138
137
138
528
140
191
310
100
138
139
684
340
21
99
36
449
90
600
21
102
91
34
511
147
169
151
174
152
154
166
162

Tab 378


241
242
5
35
131
132
32
131
132
692
34
3
29
34
511
511
692
28
45
44
43
41
46
28
31
30
27
63
61
59
2
70
21
36
33
73
72
600
33
259
99
511
511
765
98
421
686
80
92
764
182
99
421
138
137
138
140
191
472
100
138
139
310
340
99
21
449
36
90
102
600
21
91
34
684
135
511
151
174
154
152
166
162
147
169
693
4

NOTE :

BAXI S.p.A.
Via Trozzetti, 20
36061 BASSANO DEL GRAPPA (VI) ITALY
Tel. +390424517111 Telefax +390424517379
Web site: www.baxi.it e-mail: service@baxi.it