


IGUANA CIRCO

Инструкция по монтажу
Instructions de montage
Montagehinweis
Mounting instructions

Для перекрытия колонны
Revêtement de pillier
Säulenverkleidung
Pillar cover



РУС

Термоголовка для клапана
заказывается отдельно
5094.430 (не включено)



F

La tête thermostatique pour la vanne
5094.430 doit être commandée séparé-
ment (non fournie).

D

Der Thermostatkopf für das Ventil
5094.430 soll separat mitbestellt wer-
den (wird nicht mitgeliefert).

E

The thermostatic head 5094.430 has to
be ordered separately (not included).

Код:

5090.1110

Код:


5090.1111

Код:

5090.1104





25



18

19

20




Втулка для соединения арматуры: см. прайс-лист Jaga.
Klemmingschraubungen für Ventile: siehe Jaga Preisliste
Raccords bicones pour vanes: voir liste des prix Jaga
Sleeve couplings for valves: see Jaga price list



**РАЗМЕРЫ
DIMENSIONS
ABMESSUNGEN
DIMENSIONS**

Ø	27.8	31.3	34.8
E	7.5	9.4	11.3
Z	11.0	12.5	16.0




1
ФАЗА 1: РАЗМЕСТИТЬ ХГ ТРУБЫ
PHASE 1: POSITIONNER LES TUYAUX DE C.C.
FASE 1: POSITIONIERUNG Z. H. LEITUNGEN
PHASE 1: PLACEMENT OF C.H. TUBES

Ø	27.8	31.3	34.8
E	7.5	9.4	11.3
Z	11	12.5	16
Y	2	3.3	3.5


$Y = E - (Z/2)$

Min 11.5 cm
± 0.5 cm


2
ФАЗА 2: УСТАНОВКА КРОШТЕЙНОВ
PHASE 2: MONTAGE DES FIXATIONS
FASE 2: MONTAGE DER AUFHANGBÜGEL
PHASE 2: MOUNTING OF THE BRACKETS



3
ФАЗА 3: ПОДГОТОВКА КОЛОННЫ
PHASE 3: PREPARATION DE LA COLONNE DE FIXATION
FASE 3: VORBEREITUNGSARBEI
PHASE 3: PREPARATION OF THE COLUMN



ФАЗА 4: ПОДГОТОВКА ЧАСТЕЙ ИГУАНА
 PHASE 4: PREPARATION DES PIÈCES DETACHÉES DE L'IGUANA
 FASE 4: VORBEREITUNG IGUANA UNTERTEILE
 PHASE 4: PREPARATION IGUANA PARTS



ФАЗА 5: МОНТАЖ ИГУАНА СИРКО
 PHASE 5: ASSEMBLAGE DE L'IGUANA CIRCO
 FASE 5: ZUSAMMENSETZUNG IGUANA CIRCO
 PHASE 5: ASSEMBLY IGUANA CIRCO

